


**SUPERPROX<sup>+</sup>™**  
**Configuration Program**  
**and**  
**AC441/AC441A Handheld Configurator**  
**Operating Instructions**

Version 1.6A  
March 17, 2016



**Telemecanique**

1875 Founders Drive  
Dayton, Ohio 45420-4017  
Phone (937) 252-2121 Fax (937) 258-5830  
[www.tesensors.com](http://www.tesensors.com)  
[applications@tesensors.com](mailto:applications@tesensors.com)

Schneider Electric and logo, Hyde Park, OsiSense, Superprox, Superprox+, and Virtu are trademarks or registered trademarks of Schneider Electric or its affiliates in the United States and other countries. Other trademarks used herein are the property of their respective owners.

© 2000-2016 Schneider Electric. All Rights Reserved.

## Table of Contents

<b>Introduction .....</b>	<b>1</b>
<b>Requirements .....</b>	<b>1</b>
<b>Installation .....</b>	<b>1</b>
Installation from CD-ROM.....	1
Removal of Software from Computer .....	2
Running the Software .....	2
<b>Main Program Screen .....</b>	<b>3</b>
<b>SUPERPROX+ Distance Units.....</b>	<b>4</b>
<b>SUPERPROX+ Program Control Bar .....</b>	<b>4</b>
<b>SUPERPROX+ Program Dropdown Menus.....</b>	<b>5</b>
<b>Programming SC300 Series Sensors .....</b>	<b>6</b>
<b>Programming SC600 or SC606 Series Sensors .....</b>	<b>8</b>
<b>Programming SC900 or SC906 Series Sensors .....</b>	<b>10</b>
<b>Programming VC1 / VC18 Discrete or Analog Sensors .....</b>	<b>11</b>
<b>Uploading from SC300 Series Sensors.....</b>	<b>13</b>
<b>Uploading from SC600 or SC606 Series Sensors .....</b>	<b>15</b>
<b>Uploading from SC900 or SC906 Series Sensors .....</b>	<b>17</b>
<b>Uploading from VC1 / VC18 Discrete or Analog Sensors .....</b>	<b>18</b>
<b>Editing a Sensor Configuration .....</b>	<b>20</b>
To make a new model .....	20
To make permanent changes to an existing model .....	20
To make a one time change to a model.....	20

<b>Sensor Simulation.....</b>	<b>21</b>
<b>Configuration - General Concepts .....</b>	<b>22</b>
<b>SC300 Configuration Parameters .....</b>	<b>23</b>
<b>SC600 Configuration Parameters (Including AA Option).....</b>	<b>27</b>
<b>SC606 Configuration Parameters (Including AA Option).....</b>	<b>33</b>
<b>SC900 Configuration Parameters .....</b>	<b>36</b>
<b>SC906 Configuration Parameters .....</b>	<b>47</b>
<b>VC1-N / VC18-N and VC1-P / VC18-P Discrete Configuration Parameters .....</b>	<b>51</b>
<b>VC1-C / VC18-C and VC1-V / VC18-V Analog Configuration Parameters .....</b>	<b>56</b>
<b>Other Topics .....</b>	<b>60</b>
SM906 - Sliding Valid Window.....	60
SM902 -Teaching the Alarm Limit with the Pushbutton .....	61
SM903 - Teaching Delays with the Pushbutton.....	61
SM906 – Teaching Analog Response with Pushbutton.....	62
SM900 / SM906 -Dual Power Mode.....	62
SM606 / SM900 / SM906 / VM1 Analog -Exponential Averaging.....	62
SM900 / SM906 / VM1 - Echo Suppression.....	63
SM900 -Proximity Pulse Length .....	63
<b>Troubleshooting.....</b>	<b>64</b>
<b>Appendix A - AC441 and AC441A Handheld Configurator .....</b>	<b>65</b>

## Introduction

Welcome to the Schneider Electric Sensor Competency Center SUPERPROX+ sensor configuration program. This configuration program is designed to configure all parameters used in the SC3, SC6, SC9 and VC1/VC18 series sensors. The SC and VC series sensors are field configurable, while the SM and VM series sensors are not field configurable. The SUPERPROX+ configuration program allows you to configure Schneider Electric world class ultrasonic sensors. In addition, it allows you to simulate the sensor's outputs and LEDs with a simulation object. This simulation lets you verify the configuration operation before programming the sensor.

With this program you can program sensors with *standard* configurations from Schneider Electric SCC or with *custom* configurations created by you. You can create and change custom configurations. You cannot delete or change the standard configurations from Schneider Electric SCC. However, you can open a standard configuration, modify it, and then save the modified configuration in your custom directory. When the program asks for a model to open or program, you can switch between the standard and custom configurations with the *standard* and *custom* selection buttons.

The program has on-line help plus a printable manual. Pausing the cursor over any configuration parameter, displays a popup window which explains that configuration parameter.

The distance units can be changed from English units (inches) to Metric units (millimeters) with the SETUP dropdown menu selection.

## Requirements

This program requires Microsoft® XP, Windows Vista®, or Windows 7. Also required is an AC441 or AC441A Handheld Configurator and a reconfigurable sensor. Reconfigurable sensors have SC or VC prefix instead of SM or VM. An AC441A is required for all VC series sensors and single output SC300 sensors.

## Installation

### Installation from CD-ROM

1. Insert the SUPERPROX+ Configuration Program CD into CD-ROM drive. The setup program should autorun.
2. If the setup CD does not autorun, do the following:
  - Click on the **Start** menu icon.
  - Choose **Run** from the list.
  - Click **Browse** button.
  - Navigate to **D:** (If your CD drive is not drive D, use the correct drive letter)
  - Click on **Superprox+Setup.exe** and then click on the **Open** button.
3. Follow the menus through the installation process. The setup program installs the SUPERPROX+ Configuration software onto your computer along with placing an optional icon on your desktop for easy access.

To upgrade the program to latest release, just run the setup installation program for the latest release. The previous version does not have to be uninstalled.

### Removal of Software from Computer

1. Click on the **Start** menu icon.
2. Move the mouse pointer to **Programs**, then **Hyde Park SUPERPROX+**, and then click on **Uninstall SUPERPROX+**.
3. When asked to remove the programs, click **YES**.


The uninstall program does not remove the directories created by the installation program or any configuration files you created.

### Running the Software

The installation program optionally puts an icon on your desktop labeled *Hyde Park Superprox+*. Double click the **Hyde Park Superprox+** icon to run the SUPERPROX+ Configuration program. If you did not request a *Hyde Park Superprox+* desktop icon during installation, you can run the program by clicking the **Start** menu icon, then moving mouse pointer to **Programs**, then **Hyde Park SUPERPROX+**, and then click on **SUPERPROX+**.


## Main Program Screen

When you start the SUPERPROX+ program, it presents a screen from which you can choose the sensor type that you are programming.



Click the button for the type sensor you wish to program or edit. This presents a popup window with a listbox of the all the different model sensors of that type. The sensor model can be read from the sensor's label.

The following popup shows the models presented when the "Discrete (On/Off)" button is clicked. Pause the mouse over any model for a brief description of that model. Similar popups appear for the other selection buttons.











## SUPERPROX+ Distance Units

The SUPERPROX+ program can display distances in either inches or millimeters. Select any sensor type from the main program screen. Next select the SETUP dropdown menu selection, select DISTANCE UNITS, and select the desired distance units.

## SUPERPROX+ Program Control Bar

Located under the program title and dropdown menus is a control bar with buttons. These buttons allow easy access to the commonly used program operations. These buttons become enabled or disabled based upon the current operation.





Button	Description
	Quits the program.
	Creates a new model for editing. When clicked, the program presents a screen of model profiles as a starting point for the new model.
	Opens a model for either editing or programming. When clicked, the program presents a list of model numbers from the <i>Standard</i> models directory. From here you can either select a <i>standard</i> model or click the <i>custom</i> button to select a <i>custom</i> model created by you. Pausing the cursor on any model, displays a model summary description.
	Saves changes to the current model or creates a new model. To create a new model, change the model number to an unused model number, and then click this button. The program warns you if you are changing an existing model. Models you create are saved to the <i>Custom</i> models directory. You cannot save models to the <i>Standard</i> models directory, which are the models provided by Schneider Electric.
	Closes the current model, which then presents a blank screen. If changes have been made to the model, the program warns you that the changes will be lost unless you click CANCEL to the program alert message box.
	Programs a sensor. If a model is currently being displayed, that model is programmed into the sensor. If a model is not being displayed, the program presents a list of model numbers as in the OPEN button above. When a model is selected, that model is programmed into the sensor.
	Prints the current configuration to a printer.



## SUPERPROX+ Program Dropdown Menus

Under the program title are four dropdown menu selections.




Menu	Item	Description
File	New Model	Same as NEW button.
	Open Model	Same as OPEN button.
	Save Model	Same as SAVE button.
	Close Model	Same as CLOSE button
	Delete Model	Presents a list of custom models from which can select a model to delete. You can only delete models you have created.
	Program Model	Same as PROG button
	Upload from Sensor	Uploads the configuration parameters from a sensor, and then displays the configuration parameters from that sensor.
	Print Model	Same as PRINT button.
	Import Model	Copies an external model configuration file to this model's custom directory.
	Exit	Same as QUIT button
Setup	Serial Port	Selects serial port to communicate with the sensor via the AC441.
	Distance Units	Selects distances to be displayed in either English Units (inches) or Metric units (millimeters). This does not affect the distance units in the SC900/SC906 Distance Display diagnostic.
Diagnostics	Diag Window	Opens a diagnostic window which might be useful if problems occur configuring a sensor.
	Test Com Port	Tests the communication and serial port connected from the PC to the AC441.
	Distance Display	SC900/SC906 only. Displays the object distance from the sensor, which is the same distance as displayed by AC441 LED display. The distance units are determined by the AC441. To change the distance units at the AC441, with the AC441 MODE button pressed, power up the AC441, and when the distance units are displayed; continue pressing the AC441 <b>MODE</b> button and press and release the AC441  button to toggle the distance units. The distance units are either "Inch" or "Eur".
Help	Help	Presents online help for this program.
	Manual	Opens this manual with Acrobat viewer.
	Terms and Conditions	Displays the Copyright, Disclaimer of Warranties, and Limitations of Liability.
	Website	Opens your web browser and then visits Schneider Electric Sensor Competency Center's website.
	About	Displays the program version and name.

## Programming SC300 Series Sensors



This procedure programs a model's configuration into an SC300 series sensor. To determine the model, replace SC300, SC330, SC340, SC350, SC360, SC380, SC390, SC3A0 or SC3B0 with SM300, and drop the FP(flat profile) suffix. **The SC330, SC340, SC3A0 and SC3B0 3-wire sensors require the AC441A.**

Model	Use	Set	Outputs	Description
SC300	AC441 or AC441A	300	NPN=Blk, PNP=Wht	4-wire cable model
SC330	AC441A only	300P	PNP=Blk	3-pin M8 connector
SC340	AC441A only	300n	NPN=Blk	3-pin M8 connector
SC350	AC441 or AC441A	300	NPN=Blk, PNP=Wht	4-pin M8 connector
SC360	AC441 or AC441A	300	PNP=Blk, NPN=Wht	4-pin M8 connector, outputs reversed
SC380	AC441 or AC441A	300	NPN=Blk, PNP=Wht	4-pin M12 pigtail connector
SC390	AC441 or AC441A	300	PNP=Blk, NPN=Wht	4-pin M12 pigtail connector, outputs reversed
SC3A0	AC441A only	300P	PNP=Blk	4-pin M12 pigtail connector (3-pins connected)
SC3B0	AC441A only	300n	NPN=Blk	4-pin M12 pigtail connector (3-pins connected)

1. Connect the sensor to the AC441 as indicated in drawing below. Connect your PC Serial Communication port to the AC441 DB9 connector with a DB9 serial extension cable. The PC Serial Communication port can be specified with the program SETUP dropdown menu.
2. Plug the AC441 transformer into AC power and other end into the AC441 power connector.
3. For other than SC330, SC340, SC3A0, and SC3B0, press and release the AC441  button scrolling through models until 300 is displayed. If 300 does not show up in the display, then scroll through models until 600 is displayed. For SC330 or SC3A0 scroll down until 300P is displayed, and for SC340 or SC3B0 scroll down until 300n is displayed. 300P indicates 300 PNP and 300n indicates 300 NPN.
4. Double click on the **Hyde Park Superprox+** desktop icon, and then click the button for the desired sensor type, which presents a list of models of that type. Double click the desired model, which runs that sensor's model configuration program. The sensor model can be read from the sensor's label. Next click the **PROG** button on the control bar, which displays a screen of models. Double click the model to program into the sensor. The program displays a help box explaining how to power up the sensor. Hold the sensor so the sensor face is against the AC441 under the white bar located at the top-right of the AC441, and centered between the top and bottom of the AC441 box. With the other hand, press and release the AC441 **ENTER** button, which powers up the sensor. While the sensor is powered up, the AC441 illuminates the decimal points. If the help box does not disappear after you power up the sensor, try powering the sensor off and on again. Pressing and releasing the AC441 **ENTER** button toggles the sensor's power. If programming the sensor is unsuccessful, see the troubleshooting section (page 64). If still unable to program the sensor, verify that you have a field configurable sensor which has the SC prefix, and that the sensor is wired correctly to the AC441. While programming, the program displays

the locations in the sensor being programmed on the program STATUS bar at the bottom of program screen.


- When finished programming, the program displays a message that the programming was either successful or unsuccessful. If successful, click the **OK** button to complete the programming and press the AC441 **ENTER** button to turn off power to the sensor. If unsuccessful, press the AC441 **ENTER** button to turn off power to the sensor, and try the process again.



## Programming SC600 or SC606 Series Sensors


This procedure programs a model's configuration into an SC600 or SC606 series sensor, including the AA option (remote limit setup) models. The same model configuration is used for similar 18 mm cable, 18 mm connector, flat-profile cable, and flat-profile connector models. To determine the model, replace SC60, SC65 or SC66 with SM60, and drop the FP(flat profile) suffix. SC60x specifies a cable model, SC65x specifies a connector model, and SC660 specifies a discrete connector model with the NPN and PNP outputs reversed.

Model	Type	Set	Outputs	Description
SC600	Discrete	600	NPN=Blk, PNP=Wht	4-wire cable model
SC650	Discrete	600	NPN=Blk, PNP=Wht	4-pin M12 connector
SC660	Discrete	600	PNP=Blk, NPN=Wht	4-pin M12 connector, outputs reversed
SC606	Analog	606	Output=Blk	4-wire cable model
SC656	Analog	606	Output=Blk	4-pin M12 connector



1. Connect the sensor to the AC441 as indicated in drawing below. Note the difference in the black-wire and white-wire connections between an SC600/SC650 and an SC660/SC606/SC656. Connect your PC Serial Communication port to the AC441 DB9 connector with a DB9 serial extension cable. The PC Serial Communication port can be specified with the program **SETUP** dropdown menu.
2. Plug the AC441 transformer into AC power and other end into the AC441 power connector.
3. Press and release the AC441  button scrolling through models until 600 or 606 as required is displayed.
4. Double click on the **Hyde Park Superprox+** desktop icon, and then click the button for the desired sensor type, which presents a list of models of that type. Double click the desired model, which runs that sensor's model configuration program. The sensor model can be read from the sensor's label. Next click the **PROG** button on the control bar, which displays a screen of models. Double click the model to program into the sensor. The program displays a help box explaining how to power up the sensor. Hold the sensor so the sensor face is against the AC441 under the white bar located at the top-right of the AC441, and centered between the top and bottom of the AC441 box. With the other hand, press and release the AC441 **ENTER** button, which powers up the sensor. While the sensor is powered up, the AC441 illuminates the decimal points. If the help box does not disappear after you power up the sensor, try powering the sensor off and on again. Pressing and releasing the AC441 **ENTER** button toggles the sensor's power. If programming the sensor is unsuccessful, see the troubleshooting section (page 64). If still unable to program the sensor, verify the sensor model series (SC600, SC660, or SC606) matches the configuration program (SC600/SC660/SC606), that you have a field configurable sensor, and that the sensor is wired correctly to the AC441. While programming, the program displays the locations in the sensor being programmed on the program **STATUS** bar at the bottom of program screen.
5. When finished programming, the program displays a message that the programming was either successful or unsuccessful. If successful, click the **OK** button to complete the programming and press the AC441 **ENTER** button to turn off power to the sensor. If unsuccessful, press the AC441 **ENTER** button to turn off power to the sensor, and try the process again.

SC600/SC650/SC660 Wiring to AC441/AC441A (Note the black and white wire differences.)

SC600/SC650




SC606/SC656/SC660




The SC660 has reversed outputs; a white-wire NPN and black-wire PNP output.

## Programming SC900 or SC906 Series Sensors

This procedure programs a model's configuration into an SC900 or SC906 series sensor. The same model configuration is used for both cable and connector models. To determine the model, replace SC90 and SC95 with SM90. SC90x specifies a cable model, and SC95x specifies a connector model.

1. Connect the sensor to the AC441 as indicated in drawing below. Connect your PC Serial Communication port to the AC441 DB9 connector with a DB9 serial extension cable. The PC Serial communications port can be specified with the program SETUP dropdown menu.
2. Plug the AC441 transformer into AC power and other end into AC441 power connector.
3. Press and release the AC441  button scrolling through models until 900 or 906 as required is displayed.
4. Double click on the **Hyde Park Superprox+** desktop icon, and then click the button for the desired sensor type, which presents a list of models of that type. Double click the desired model, which runs that sensor's model configuration program. The sensor model can be read from the sensor's label. Next click the **PROG** button on the control bar, which displays a screen of models. Double click on the models to program into the sensor. The program displays a help box that the program is attempting communication with the sensor. When the sensor is powered up, the AC441 illuminates the decimal points. While programming, the program displays status information. If programming the sensor is unsuccessful, see the troubleshooting section (page 64). If still unable to program the sensor, verify the sensor model series (SC900 or SC906) matches the configuration program (SC900 or SC906), and that you have a reconfigurable sensor, and that the sensor is wired correctly to the AC441.
5. While programming, the program displays status messages that indicate the current operation.
6. When finished programming, the program displays message that the programming was either successful or unsuccessful. If successful, click to **OK** button to complete. If unsuccessful, click to **OK** button to abort, and then try programming again.





## Programming VC1 / VC18 Discrete or Analog Sensors


This procedure programs a model's configuration into a Virtu™ model VC1-N / VC18-N or VC1-P / VC18-P Discrete sensor or VC1-C / VC18-C or VC1-V / VC18-V Analog sensor. The same model configuration is used for similar VC1 / VC18 cable or connector models. **Programming these sensors requires the AC441A.**

Model	AC441A	Output	Description
VC1-N / VC18-N	300n	NPN=Blk	Discrete with NPN output
VC1-P / VC18-P	300P	PNP=Blk	Discrete with PNP output
VC1-C / VC18-C	300P	Current=Blk	Analog with Current output
VC1-V / VC18-V	300P	Voltage=Blk	Analog with Voltage output


Note: Program the VC18 sensors exactly like the VC1 sensors.

1. Connect the sensor to the AC441A as indicated in the drawing below. Connect your PC Serial Communication port to the AC441A DB9 connector with a DB9 serial extension cable. The PC Serial Communication port can be specified with the program SETUP dropdown menu.
2. Plug the AC441A transformer into AC power and other end into the AC441A power connector.
3. For the VC1-P, VC1-C, and VC1-V, press and release the AC441A  button scrolling through models until 300P is displayed. For the VC1-N, press and release the AC441A  button scrolling through models until 300n is displayed.
4. Double click on the **Hyde Park Superprox+** desktop icon, and then click the button for the desired sensor type, which presents a list of models of that type. Double click the desired model, which runs that sensor's model configuration program. The sensor model can be read from the sensor's label. Next click the **PROG** button on the control bar, which displays a screen of models. Double click the model to program into the sensor. The program displays a help box explaining how to power up the sensor. With the PB100 pushbutton pressed (white wire grounded) or the sensor face facing the white bar located at the top-right of the AC441A, press and release the AC441A **ENTER** button, which powers up the sensor. While the sensor is powered up, the AC441A illuminates the decimal points. If the help box does not disappear after you power up the sensor, try powering the sensor off and on again. Pressing and releasing the AC441A **ENTER** button toggles the sensor's power. If programming the sensor is unsuccessful, see the troubleshooting section (page 64). If still unable to program the sensor, verify the sensor model series matches the configuration program, that you have a field configurable sensor, and that the sensor is wired correctly to the AC441A. While programming, the program displays the locations in the sensor being programmed on the program STATUS bar at the bottom of program screen.
5. When finished programming, the program displays a message that the programming was either successful or unsuccessful. If successful, click the **OK** button to complete the programming and press the AC441A **ENTER** button to turn off power to the sensor. If unsuccessful, press the AC441A **ENTER** button to turn off power to the sensor, and try the process again.

### Virtu™ VC1-V / VC1-C / VC1-P Wiring to AC441A



### Virtu™ VC1-N Wiring to AC441A








## Uploading from SC300 Series Sensors

This procedure uploads a model's configuration from an SC300 series sensor to the PC. **The SC330, SC340, SC3A0 and SC3B0 3-wire sensors require the AC441A.**

Model	Use	Set	Outputs	Description
SC300	AC441 or AC441A	300	NPN=Blk, PNP=Wht	4-wire cable model
SC330	AC441A only	300P	PNP=Blk	3-pin M8 connector
SC340	AC441A only	300n	NPN=Blk	3-pin M8 connector
SC350	AC441 or AC441A	300	NPN=Blk, PNP=Wht	4-pin M8 connector
SC360	AC441 or AC441A	300	PNP=Blk, NPN=Wht	4-pin M8 connector, outputs reversed
SC380	AC441 or AC441A	300	NPN=Blk, PNP=Wht	4-pin M12 pigtail connector
SC390	AC441 or AC441A	300	PNP=Blk, NPN=Wht	4-pin M12 pigtail connector, outputs reversed
SC3A0	AC441A only	300P	PNP=Blk	4-pin M12 pigtail connector (3-pins connected)
SC3B0	AC441A only	300n	NPN=Blk	4-pin M12 pigtail connector (3-pins connected)

1. Connect the sensor to the AC441 as indicated in drawing below. Connect your PC Serial Communication port to the AC441 DB9 connector with a DB9 serial extension cable. The PC Serial Communication port can be specified with the program SETUP dropdown menu.
2. Plug the AC441 transformer into AC power and other end into the AC441 power connector.
3. For other than SC330, SC340, SC3A0, and SC3B0, press and release the AC441  button scrolling through models until 300 is displayed. If 300 does not show up in the display, then scroll through models until 600 is displayed. For SC330 and SC3A0, scroll down until 300P is displayed, and for SC340 and SC3B0, scroll down until 300n is displayed. 300P indicates 300 PNP and 300n indicates 300 NPN.
4. Double click on the **Hyde Park Superprox+** desktop icon, and then click the button for the desired sensor type, which presents a list of models of that type. Double click the desired model, which runs that sensor's model configuration program. The sensor model can be read from the sensor's label. Next click the program dropdown **File** selection and then **Upload from Sensor**. The program displays a help box explaining how to power up the sensor. Hold the sensor so the sensor face is against the AC441 under the white bar located at the top-right of the AC441, and centered between the top and bottom of the AC441 box. With the other hand, press and release the AC441 **ENTER** button, which powers up the sensor and loads the configuration data from the sensor. While the sensor is powered up, the AC441 illuminates the decimal points. If the help box does not disappear after you press the AC441 **ENTER** button, try powering the sensor off and on again. Pressing and releasing the AC441 **ENTER** button toggles the sensor power. If uploading from the sensor is unsuccessful, see the troubleshooting section (page 64). If still unable to program the sensor, verify that you have a field configurable sensor, which has a SC prefix, and that the sensor is wired correctly to AC441. While programming, the program displays the locations in the sensor being programmed on the program STATUS bar, which is at the bottom of program screen.


5. When finished uploading, if successful the program displays the configuration data from the sensor. Press the AC441 **ENTER** button to turn off power to the sensor. If unsuccessful, a failure message is displayed. Click the **OK** button to abort the uploading, press the AC441 **ENTER** button to turn off power to the sensor, and try the process again



## Uploading from SC600 or SC606 Series Sensors


This procedure uploads the configuration from an SC600 or SC606 series sensor to the PC.

Model	Type	Set	Outputs	Description
SC600	Discrete	600	NPN=Blk, PNP=Wht	4-wire cable model
SC650	Discrete	600	NPN=Blk, PNP=Wht	4-pin M12 connector
SC660	Discrete	600	PNP=Blk, NPN=Wht	4-pin M12 connector, outputs reversed
SC606	Analog	606	Output=Blk	4-wire cable model
SC656	Analog	606	Output=Blk	4-pin M12 connector



1. Connect the sensor to the AC441 as indicated in drawing below. Note the difference in the black- and white-wire connection between an SC600 and SC660/SC606. Connect your PC Serial Communication port to the AC441 DB9 connector with a DB9 serial extension cable. The
2. Plug the AC441 transformer into AC power and other end into the AC441 power connector.
3. Press and release the AC441  button scrolling through models until 600 or 606 as required is displayed.
4. Double click on the **Hyde Park Superprox+** desktop icon, and then click the button for the desired sensor type, which presents a list of models of that type. Double click the desired model, which runs that sensor's model configuration program. The sensor model can be read from the sensor's label. Next click the program dropdown **File** selection and then **Upload from Sensor**. The program displays a help box explaining how to power up the sensor. Hold the sensor so the sensor face is against the AC441 under the white bar located at the top-right of the AC441, and centered between the top and bottom of the AC441 box. With the other hand, press and release the AC441 **ENTER** button, which powers up the sensor and loads the configuration data from the sensor. While the sensor is powered up, the AC441 illuminates the decimal points. If the help box does not disappear after you press the AC441 **ENTER** button, try powering the sensor off and on again. Pressing and releasing the AC441 **ENTER** button toggles the sensor power. If uploading from the sensor is unsuccessful, see the troubleshooting section (page 64). If still unable to program the sensor verify the sensor model series (SC600, SC660, or SC606) matches the configuration program (SC600/SC660/SC606), that you have a field configurable sensor, and that the sensor is wired correctly to the AC441. While programming, the program displays the locations in the sensor being programmed on the program STATUS bar, which is at the bottom of program screen.
5. When finished uploading, if successful the program displays the configuration data from the sensor. Press the AC441 **ENTER** button to turn off power to the sensor. If unsuccessful, a failure message is displayed. Click the **OK** button to abort the uploading, press the AC441 **ENTER** button to turn off power to the sensor, and try the process again

SC600/SC650/SC660 Wiring to AC441/AC441A (Note the black and white wire differences.)

SC600/SC650




SC606/SC656/SC660




The SC660 has reversed outputs; a white-wire NPN and black-wire PNP output.

## Uploading from SC900 or SC906 Series Sensors

This procedure uploads the configuration from an SC900 or SC906 series sensor to the PC.

1. Connect the sensor to the AC441 as indicated in drawing below. Connect your PC Serial Communication port to AC441 DB9 connector with a DB9 serial extension cable. The PC Serial communications port can be specified with the program SETUP dropdown menu.
2. Plug the AC441 transformer into AC power and other end into the AC441 power connector.
3. Press and release the AC441  button scrolling through models until 900 or 906 as required is displayed.
4. Double click on the **Hyde Park Superprox+** desktop icon, and then click the button for the desired sensor type, which presents a list of models of that type. Double click the desired model, which runs that sensor's model configuration program. The sensor model can be read from the sensor's label. Next click the program dropdown **File** selection and then **Upload from Sensor**. The program displays a help box that the program is attempting communication with the sensor. When the sensor is powered up, the AC441 illuminates the decimal points. If unable to upload from the sensor, see the troubleshooting section (page 64). If still unable to upload from the sensor, verify the sensor model series (SC900 or SC906) matches the configuration program (SC900 or SC906), that you have a reconfigurable sensor, and that the sensor is wired correctly to the AC441.
5. While uploading, the program displays status messages that indicate the current operation.
6. When finish uploading, if successful, the program displays the configuration from the sensor. If unsuccessful, a failure message is displayed. Click the **OK** button to abort the uploading, and try again.



## Uploading from VC1 / VC18 Discrete or Analog Sensors


This procedure uploads the configuration from a Virtu™ VC1-N / VC18-N or VC1-P / VC18-P Discrete sensor or VC1-C / VC18-C or VC1-V / VC18-V Analog sensor to the PC.

Model	AC441A	Output	Description
VC1-N / VC18-N	300n	NPN=Blk	Discrete with NPN output
VC1-P / VC18-P	300P	PNP=Blk	Discrete with PNP output
VC1-C / VC18-C	300P	Current=Blk	Analog with Current output
VC1-V / VC18-V	300P	Voltage=Blk	Analog with Voltage output


Note: Upload the VC18 sensors exactly like the VC1 sensors.

1. Connect the sensor to the AC441A as indicated in drawing below. Connect your PC Serial Communication port to the AC441A DB9 connector with a DB9 serial extension cable. The
2. Plug the AC441A transformer into AC power and other end into the AC441A power connector.
3. For the VC1-P, VC1-C, and VC1-V, press and release the AC441A ▲ button scrolling through models until 300P is displayed. For the VC1-N, press and release the AC441A ▲ button scrolling through models until 300n is displayed.
4. Double click on the **Hyde Park Superprox+** desktop icon, and then click the button for the desired sensor type, which presents a list of models of that type. Double click the desired model, which runs that sensor's model configuration program. The sensor model can be read from the sensor's label. Next click the program dropdown **File** selection and then **Upload from Sensor**. The program displays a help box explaining how to power up the sensor. With the PB100 pushbutton pressed (white wire grounded) or the sensor face facing the white bar located at the top-right of the AC441A, press and release the AC441A **ENTER** button, which powers up the sensor. While the sensor is powered up, the AC441A illuminates the decimal points. If the help box does not disappear after you press the AC441A **ENTER** button, try powering the sensor off and on again. Pressing and releasing the AC441A **ENTER** button toggles the sensor power. If uploading from the sensor is unsuccessful, see the troubleshooting section (page 64). If still unable to upload the sensor verify the sensor model series matches the configuration program, and that you have a field configurable sensor. While programming, the program displays the locations in the sensor being programmed on the program STATUS bar, which is at the bottom of program screen.
5. When finished uploading, if successful the program displays the configuration data from the sensor. Press the AC441A **ENTER** button to turn off power to the sensor. If unsuccessful, a failure message is displayed. Click the **OK** button to abort the uploading, press the AC441A **ENTER** button to turn off power to the sensor, and try the process again

### Virtu™ VC1-V / VC1-C / VC1-P Wiring to AC441A



### Virtu™ VC1-N Wiring to AC441A



## Editing a Sensor Configuration

Double click on the **Hyde Park Superprox+** desktop icon, and then click the button for the desired sensor type, which presents a list of models of that type. Double click the desired model, which runs that sensor's model configuration program. The sensor model can be read from the sensor's label. Next click the **OPEN** button from the control bar, which displays a screen of models that are valid for that sensor type. Click the **CUSTOM** button to switch to configurations defined by you. Click the **STANDARD** button to switch to configuration supplied by Schneider Electric. Double click the model you wish to edit. The program then displays the configuration parameters for that configuration. Based on the model, there are either 2 or 3 pages of parameters. Click the page tabs under the model description to switch between the pages of parameters.

When a model is displayed, to change a parameter field either press the TAB or <shift>TAB key until the desired parameter is highlighted, or click the left mouse button on the parameter field. For text and numeric fields, type in the new value for the field. For dropdown list selections, click the arrow next to the parameter, and then select the desired option.

For help about any configuration parameter, pause the cursor pointer on the parameter field. A popup window appears which explains the configuration parameter.

### To make a new model

1. Click the **OPEN** button. A screen of existing model configurations is displayed.
2. Double click a model similar to the new configuration desired.
3. Change the model number and make the desired changes to the configuration.
4. Click the **SAVE** button. The new model is saved to your custom directory.

**or**

1. Click the **NEW** button. A small window of sensor profiles is displayed.
2. Double click on the desired sensor profile.
3. Change the model number and make the desired changes to the configuration.
4. Click the **SAVE** button. The new model will be saved to your custom directory.

### To make permanent changes to an existing model

The *Standard* models from Schneider Electric cannot be changed. You can only change models that you created. The models you create are saved in the *Custom* directory of models. You can use the standard models from Schneider Electric to create new models.

1. Click the **OPEN** button. A screen of all standard existing models is displayed.
2. Click the **CUSTOM** button to display the custom models. A screen of custom models is displayed.
3. Double click the model to change.
4. Make the desired changes to the model.
5. Click the **SAVE** button. Click **OK** to overwrite the current model.


### To make a one time change to a model

1. Click the **OPEN** button. A screen of models is displayed.
2. Double click the model to program from either the *Standard* or *Custom* models.
4. Make the desired changes to the model.
5. Click the **PROG** button to program the changed model. (See programming Sensor above)



## Sensor Simulation

The operation of the sensor can be simulated by dragging the target, which is the rectangle currently between the two limits, with the mouse. To set the target to no echo, either move the target all the way to the right or move the target to the top of the simulation window.



## Configuration - General Concepts

Cycles: The response time and delays are specified in cycles. See the next paragraph.

Cycle Time: The sensors operate in pulse echo mode, which means the sensor periodically sends a burst of ultrasonic energy and then listens for an echo return. This period between bursts is referred to as cycle time. All processing is done once every cycle. The cycle time must be large enough for the sound to travel to the maximum range and return. Also it must be large enough so that secondary echoes do not occur. See Speed-of-Sound below.

Response Time: Since processing is done once per cycle (see previous paragraph), all delays and response times are in multiples of the cycle time. The cycle time is specified either in Advanced or the Sensing Parameters. The actual response time may be a 1/2 cycle longer than the stated value, because if an object moves into the beam just after the ultrasonic energy passed, the object will not be detected until the next cycle.

Speed-of-Sound: Ultrasonic energy requires 150 microseconds to travel from the sensor face to an object at 25.4 mm (1 inch) and back to the sensor face. Therefore the minimum cycle time must be at least 6 usec times the maximum distance in millimeters (150 usec times the maximum distance in inches).

NPN is a type output that switches to ground when on. Normally the other end of the NPN load is connected to V+. NPN is often referred to as Sinking output.

PNP is a type output that switches to V+ when on. Normally the other end of the PNP load is connected to ground. PNP is often referred to as a Sourcing output.

## SC300 Configuration Parameters

### Introduction

The SC300 series sensors have one or two outputs as indicated in the table below.

Model	Outputs	Description
SC300	NPN=Blk, PNP=Wht	4-wire cable model
SC330	PNP=Blk	3-pin M8 connector
SC340	NPN=Blk	3-pin M8 connector
SC350	NPN=Blk, PNP=Wht	4-pin M8 connector
SC360	PNP=Blk, NPN=Wht	4-pin M8 connector, outputs reversed
SC380	NPN=Blk, PNP=Wht	4-pin M12 pigtail connector
SC390	PNP=Blk, NPN=Wht	4-pin M12 pigtail connector, outputs reversed
SC3A0	PNP=Blk	4-pin M12 pigtail connector (3-pins connected)
SC3B0	NPN=Blk	4-pin M12 pigtail connector (3-pins connected)

The two outputs are connected internally and are either both on or both off. In the case of the single output, the other output is not connected to the connector. The SC300 supports both Proximity and Dual Level processing. The sensors also have a bi-color LED that is either green or amber. In Proximity mode, the bi-color LED indicates the object position and is usually amber when an object is between the limits and green when no object is detected between the limits. In Dual Level mode, the bi-color LED indicates the outputs' state and is usually amber when the outputs are on and green when the outputs are off.

*Sensors manufactured before 2007 may have the amber LED in place of the green LED and a orange LED in place of the amber LED.*

*Sensors manufactured before 2004 may not support Dual Level processing, long cycle times, and large delays. This program will not allow you to load configurations with these options into these older sensors. These configuration parameters can only be checked when the sensor is being configured.*

The SC300 series sensor's parameters are separated under two tab controls: 1) Limits / Outputs and 2) Advanced Parameters. The tab controls appear just below the model description. To switch between tab controls, click the desired tab control. The parameters are explained under the tab control name under which they appear.

**Limits / Outputs** | **Advanced Parameters**

For help about any configuration parameter, pause the cursor pointer on the parameter field. A popup window appears which explains the configuration parameter.

The definitions of some of the fields are explained in more detail in "Sensing Terms" of the Schneider Electric sensors catalog.

Proximity Processing Proximity on/off processing delays. The outputs switch to one state when the object is between the limits and to the opposite state when no object is detected between the limits. The sensor LED indicates object position and is normally green when an object is not detected within limits and is amber when an object is detected within limits.


To get the sensor to appear to have 6.35 mm (1/4 inch) near limit, set the near limit closer than the deadband. This allows the sensor to use the 2nd or 3rd bounce of the echo between the sensor and the object, thus making it appear the sensor can detect objects as close as 6.4 mm (1/4 inch) from the sensor face.

Model  Processing

Desc

**Limits / Outputs** **Advanced Parameters**

Target  Deadband  Range



V+ ☐ Wht ☐ Blk ☐

Near (in.)  Far (in.)

Change On (Cycles)  N.O./N.C.

Change Off (Cycles)

Backgnd/Object


Dual-Level Processing Pump In and Pump Out operation. The outputs switch to one state when the object is closer than the near limit, the opposite state when the object is beyond the far limit, and holds when the object is within limits. The sensor LED indicates output state and is normally green when the outputs are off and amber when the outputs are on.

Model  Processing

Desc

**Limits / Outputs** **Advanced Parameters**

Target  Deadband  Range



V+ ☐ Wht ☐ Blk ☐

Near (in.)  Far (in.)

Change On (Cycles)  N.O./N.C.

Change Off (Cycles)  PumpIn/PumpOut

Loss Echo (Cycles)  Loss Echo State

### Non-Tab Control Parameters

<u>Name</u>	<u>Description</u>
Model	The number for the model, which is also the filename for this model. This number can be from 1 to 19 characters long.
Processing	Specifies the model processing. Select either Proximity or Dual Level. (Some older sensors do not support Dual Level)
Desc	A comment field that can be used to describe the model operation or any other useful information.

### Simulation Window Parameters

Near Limit(in.)	Determines the near limit of the sensor. This parameter can be changed by either dragging the limit with the mouse or typing in a limit value. For fine adjustment of limit, click the arrows below the limit. Setting this limit closer than the deadband, allows the sensor to use the 2nd or 3rd bounce of the echo between the sensor and the object, thus making it appear the sensor can detect objects as close as 6.4 mm (1/4 inch) from the sensor face.
Far Limit(in.)	Determines the far limit of the sensor. This parameter can be changed by either dragging the limit with the mouse or typing in a limit value. For fine adjustment of limit, click the arrows below the limit.

### Limits/Outputs Tab Parameters (Proximity)

Change On (Cycles)	The number of consecutive cycles the object has to be detected between the limits before the outputs change to the logical On state.
Change Off (Cycles)	The number of consecutive cycles no object can be detected between the limits before the output change to the logical Off state.
N.O./N.C.	N.O. = Outputs are sinking or sourcing when object detected between limits. N.C. = Outputs are sinking or sourcing when object not detected between limits.
Backgnd/Object	Selects either Backgnd or Object mode processing Backgnd - Sensor processes only first echo detected (standard). Object - Sensor processes multiple echoes, and assumes object is between the limits if any echo is detected between the limits.

### Limits/Outputs Tab Parameters (Dual Level)

Change On (Cycles)	PumpIn - The number of consecutive cycles the object has to be detected beyond far limit before the pump output changes to the logical ON state. PumpOut – The number of consecutive cycles the object has to be detected closer than near limit before the pump output changes to the logical ON state.
--------------------	---

Change Off (Cycles)	<p>PumpIn - The number of consecutive cycles the object has to be detected closer than the near limit before the pump output changes to the logical OFF state.</p> <p>PumpOut – The number of consecutive cycles the object has to be detected farther than the far limit before the pump output changes to the logical OFF state.</p>
N.O./N.C.	<p>N.O. = Outputs are sinking or sourcing when output is logically On.</p> <p>N.C. = Outputs are sinking or sourcing when output is logically Off.</p>
Pumpin/Pumpout	<p>PumpIn = Outputs turn logically on when object farther than far limit and logically off when object closer than near limit.</p> <p>PumpOut = Outputs turn logically on when object closer than near limit and logically off when object farther than far limit.</p>
Loss Echo (Cycles)	<p>= 0 - On echo loss, outputs hold their last known state.</p> <p>&gt; 0 - When an object is not detected for this many cycles, the outputs are set to the LOSS ECHO STATE.</p>
Loss Echo State	Determines the power up state and the echo loss state.

#### Advanced Tab Parameters

The advanced parameters should normally not be changed.

Cycle Time(usec)	This sensor sends a burst of ultrasonic energy at regular intervals, and listens for the reflection of that ultrasonic energy. This parameter determines the time between bursts of ultrasonic energy. Ultrasonic energy requires 150 microseconds to travel from the sensor face to an object at 25.4 mm (1 inch) and back to the sensor face.
Ramp Deadband (in.)	Consult Schneider Electric SCC before changing this field. The Ramp is used to decrease the sensitivity of the sensor close to the sensor face where the receive transducer is still ringing from the transmitted energy. This allows a closer deadband value.
Range Dist(in.)	The farthest distance at which the sensor can detect an object. The sensor disables its receiver at this distance. The SC300A-400 has a maximum range of 127 mm (5 inches) with a maximum far limit of 101.6 mm (4 inches).
Xmit Power	Use this parameter to change the power or ultrasonic transmit energy.
Ramp Hyst (usec.)	Proximity mode only. Consult Schneider Electric SCC before changing this field. This hysteresis shifts the ramp closer to start of burst, which effectively lowers the echo detection threshold.
Near Limit Hyst(in.)	Proximity mode only. When an object is detected within the limits, the sensor moves the near limit this much closer to the sensor to prevent output oscillation at the near limit.
Far Limit Hyst(in.)	Proximity mode only: When an object is detected within the limits, the sensor moves the far limit this much farther from the sensor to prevent output oscillation at the far limit.
Reverse LED Color	<p>Select Yes to reverse the operation of the bi-color LED as follows:</p> <p>Proximity - Green when between limits, Amber when outside limits.</p> <p>Dual Level - Green when outputs are on. Amber when outputs are off.</p>

## SC600 Configuration Parameters (Including AA Option)


### Introduction

The LED configuration parameter affects only the LED in the 18 mm cable and the flat profile models. If an AC117 connector cable is attached to an 18 mm SC650 connector model, the AC117 connector LED shows the state of black-wire NPN output. This LED is on when the black-wire NPN output is sinking and off when the black-wire NPN output is non-sinking. There is no LED for the 18 mm SC660 connector models.

The SC600/SC650 sensors have a black-wire NPN output and a white-wire PNP output. The action of these outputs are independent of each other, and is specified with configuration parameters.

The SC660 models have reverse outputs; the black-wire is a PNP output and the white-wire is an NPN output. The action of these outputs are independent of each other, and is specified with configuration parameters. If the SC660 model was selected from the main configuration screen, the black-wire and white-wire outputs are switched in the configuration parameters and in the simulation window to reflect the SC660 outputs. All examples are shown for the SC600/SC650 model series.

The SC600 series sensor's parameters are separated under two tab controls: 1) Limits / Outputs and 2) Advanced Parameters. The tab controls appear just below the model description. To switch between tab controls, click the desired tab control. The parameters are explained under the tab control name under which they appear.



**Limits / Outputs** | **Advanced Parameters**

For help about any configuration parameter, pause the cursor pointer on the parameter field. A popup window appears which explains the configuration parameter.

The definitions of some of the fields are explained in more detail in "Sensing Terms" of the Schneider Electric sensors catalog.

The SC600 supports both Proximity and Dual-Level processing. The parameters presented are determined by the selected processing mode.


Proximity Processing: Proximity on/off processing with delays. The outputs switch to one state when the object is between the limits and to the opposite state when no object is detected between the limits.

Model  Processing

Desc

**Limits / Outputs** **Advanced Parameters**

Target  Deadband  Range



V+ ☐ Wht ☐ Blk ☐

Near (in.)  Far (in.)

Zone Within Outside

PNP-Wht

NPN-Blk

LED

Change (Cycles)

LED Flash (Cycles)  Backgnd/Object


Dual-Level Processing: Dual-level operation. Dual level processing has four zones, where the action for each output can be specified by zone. The four zones are: 1) between deadband near limit, 2) between near and far limit, 3) between far limit and far range, and 4) echo loss. With Dual-level, you can specify Pump In, Pump Out, Dual Alarm, or Dual Setpoint operation.

Model  Processing

Desc

**Limits / Outputs** **Advanced Parameters**

Target  Deadband  Range



V+ ☐ Wht ☐ Blk ☐

Near (in.)  Far (in.)

Zone Near Within Far Echo Loss

PNP-Wht

NPN-Blk

LED

Change (Cycles)

LED Flash (Cycles)



### Non-Tab Control Parameters

<u>Name</u>	<u>Description</u>
Model	The number for the model, which is also the filename for this model. This number can be from 1 to 14 characters long.
Processing	Specifies the model processing. Select either Proximity or Dual Level.
Desc	A comment field that can be used to describe the model operation or any other useful information.

### Simulation Window Parameters

Near Limit(in.)	Determines the near limit of the sensor. This parameter can be changed by either dragging the limit with the mouse or typing in a limit value. For fine adjustment of limit, click the arrows below the limit.
Far Limit(in.)	Determines the far limit of the sensor. This parameter can be changed by either dragging the limit with the mouse or typing in a limit value. For fine adjustment of limit, click the arrows below the limit.

### Limits and Outputs - Proximity

The screenshot shows a control panel for Proximity Limits and Outputs. It has two columns: 'Within' and 'Outside'. Under 'Within', there are three rows: 'PNP-Wht', 'NPN-Blk', and 'LED', each with a dropdown menu set to 'On'. Below these is a 'Change(Cycles)' input field set to '2'. Under 'Outside', there are three rows: 'PNP-Wht', 'NPN-Blk', and 'LED', each with a dropdown menu set to 'Off'. Below these is a 'Change(Cycles)' input field set to '2'. At the bottom, there is an 'LED Flash (Cycles)' input field set to '0' and a 'Backgnd/Object' dropdown menu set to 'Backgnd'.

The proximity processing defines two zones: 1) Within - object is between the limits, and 2) Outside - no object is between the limits. The number of consecutive echoes required in a zone to switch to that zone is specified by the CHANGE(CYCLE) parameter for each zone. The action for the PNP output, the NPN output, and the LED can be independently set to OFF, ON, NO CHNG. The PNP output can also be set to generate a SQR WAVE, with the period and duty cycle settable with the advanced parameters. The LED can also be set to FLASHING, which is a state used for some Dual Level models.

LED flash (Cycles)	If flashing is specified for the LED, then this parameter is enabled and is the number of cycles the LED is on and then off when an object is in a flashing zone.
Backgnd/Object	Selects either Backgnd or Object mode processing Backgnd - Sensor processes only first echo detected (standard). Object - Sensor processes multiple echoes, and assumes object is between the limits if any echo is detected between the limits.

## Limits and Outputs - Dual Level

Zone	Near	Within	Far	Echo Loss
PNP-Wht	Off	No Chng	On	Off
NPN-Blk	Off	No Chng	On	Off
LED	Off	No Chng	On	Off
Change(Cycles)	2	2	2	400
LED Flash (Cycles) 0				

The dual-level processing defines four zones: 1) Near - object is closer than near limit, 2) Within - object is between the limits, 3) Far - object between far limit and far range, 4) Echo Loss - no object detected. The number of consecutive echo required to switch to a zone is specified by the CHANGE(CYCLES) parameter for each zone. The action for the PNP output, NPN output, and the LED can be independently set to OFF, ON, or NO CHNG. The PNP output can also be set to SQR WAVE, with the period and duty cycle settable with the advanced parameters. The LED can also be set to FLASHING.

For Pump-In operation, set Near = OFF, Within = NO CHNG, and Far = ON.

For Pump-Out operation, set Near = ON, Within = NO CHNG, and Far = OFF.

LED flash (Cycles)	If flashing is specified for the LED, then this parameter is enabled and is the number of cycles the LED is on and then off when an object is in a flashing zone.
--------------------	---

## Advanced Parameters

The advanced parameters should normally not be changed.

Model Gain	Used to change the receiver sensitivity of the sensor. Increasing this value increases the distance that an object can be seen. Higher gains can be used to see smaller objects. Increasing the gain, however, increases the deadband and can require a longer cycle time. The standard gain is 100.
Cycle Time(usec)	This sensor sends a burst of ultrasonic energy at regular intervals, and listens for the reflection of that ultrasonic energy. This parameter determines the time between bursts of ultrasonic energy. Ultrasonic energy requires 150 microseconds to travel from the sensor face to an object at 25.4 mm (1 inch) and back to the sensor face.
Ramp Start(in.)	Consult Schneider Electric SCC before changing this field. The Ramp is used to decrease the sensitivity of the sensor close to the sensor face where the receive transducer is still ringing from the transmitted energy. This allows a closer deadband value.
Slow Ramp	This parameter must be enabled for high gain sensors. The slow ramp decreases the sensitivity of the sensor farther from the sensor face than the normal ramp. This decreased sensitivity is needed to ignore the increased ringing near the sensor face due to the higher gain. If the MODEL GAIN is set greater than 100, then this should be set to YES.

Deadband(in.)	The transmitted ultrasonic energy causes the receive transducer to ring. The deadband is the time for this ringing to diminish to the point where the transducer can receive its echo.
Range Dist(in.)	The farthest distance at which the sensor can detect an object. The sensor disables its receiver at this distance. The SC600A-B00 has a maximum range of 279 mm (11 inches) with a maximum far limit of 254 mm (10 inches).
Burst Width(usec)	Consult Schneider Electric SCC before changing this field. Standard value is 18. The ultrasonic transmit power can be lowered by decreasing this value.
Near Hyst(in.)	When an object is detected within the limits, the sensor moves the near limit this much closer to the sensor to prevent output oscillation at the near limit.
Far Hyst(in.)	When an object is detected within the limits, the sensor moves the far limit this much farther from the sensor to prevent output oscillation at the far limit.
Hardware Hyst	When an object is detected between the near and far limits, the sensor can optionally lower the threshold detection level. This lowering of the threshold can "lock" the sensor onto a small object which is barely detectable. This lowering of the threshold causes the object to appear closer, which can prevent output oscillation at the far limit; but can cause output oscillation at near limit (see next parameter). Possible values are NONE, SMALL, LARGE, and SPECIAL. The standard value is LARGE.
Hrdwr Hyst Off(in.)	As mentioned in the previous parameter, the lowering of the echo detection threshold causes the object to appear closer. At the near limit, this causes oscillation if the distance "shift" due to lowering the threshold causes the object to appear closer than the near limit. The hardware hysteresis is turned off when an object is detected within this distance of near limit.
Temp Comp	The speed of sound changes with temperature. The sensor can be configured to compensate the receive echo distance for temperature. Since the temperature sensor is internal to the sensor and affected by internal heating, the temperature compensation takes 20 minutes after the sensor is powered to be effective. The standard value is Off. The original SM600s did not support temperature compensation, therefore to be backwards compatible the new SM600s have temperature compensation disabled.
Square Wave Divider	The PNP output can be configured to generate a square wave output in any zone. This field determines the resolution of the internal square wave timer. The next field specifies the number of counts for the square wave. When this field is selected, the program displays the number of microsecond each value represents (1 = .25 usec/cnt, 2 =.2.0 usec/cnt, ..., 5 = 256 usec/cnt). The square wave on and off times are both equal to this parameter value times the SQUARE WAVE COUNTS.
Square Wave Counts	See previous field.

AA Option (Under Advanced Tab)

Setup Limit Offsets	<p>If this parameter is zero, then two distinct limits are set, by placing the target at the first limit and momentarily grounding the limit setup wire, then placing the target at the second limit and momentarily grounding the limit setup wire.</p> <p>If this parameter is non-zero, then this is the +/- offset that the limit is set around the target. The default window is set with a single momentarily grounding of the limit setup wire. To set a 25.4 mm (1.00 in.) window, Set this parameter to 12.7 mm (0.50 in.).</p>
---------------------	--

## SC606 Configuration Parameters (Including AA Option)

The SC606 series sensor's parameters are separated under two tab controls: 1) Limits / Outputs and 2) Advanced Parameters. The tab controls appear just below the model description. To switch between tab controls, click the desired tab control. The parameters are explained under the tab control name under which they appear. There are no extra parameters for the AA option (remote limit setup).

Limits / Outputs

Advanced Parameters

For help about any configuration parameter, pause the cursor pointer on the parameter field. A popup window appears which explains the configuration parameter.

The definitions of some of the following parameters are explained in more detail in "Sensing Terms" of the Schneider Electric sensors catalog.

Model 
Current/Voltage 
Desc

Limits / Outputs

Advanced Parameters

Target 
Deadband 
Range

status

Min

Max

1.375

Near (in.)

6.000

Far (in.)

Direct/Inverse 
Resp Tau Factor 
Resp = 2500 usec

Loss Echo State 
Echo Loss (Cycles)

Analog Minimum(Volts) 
Analog Maximum(Volts)

### Non-Tab Control Parameters

Name	Description
Model	The number for the model, which is also the filename for this model. The number can be from 1 to 14 characters long.
Current/Voltage	Documentation field that shows whether this configuration is for a CURRENT or VOLTAGE analog output sensor. This parameter must match the hardware capabilities of the sensor. Before downloading a configuration to a sensor, the program verifies that the sensor hardware matches the current or voltage value.
Desc	A comment field that can be used to describe the model operation or any other useful information.

### Simulation Window Parameters

Near Limit(in.)	Determines the near limit of the sensor. This parameter can be changed by either dragging the limit with the mouse or typing in a limit value. For fine adjustment of limit, click the arrows below the limit.
Far Limit(in.)	Determines the far limit of the sensor. This parameter can be changed by either dragging the limit with the mouse or typing in a limit value. For fine adjustment of limit, click the arrows below the limit.

### Limits and Outputs

Direct/Inverse	Direct - Analog output is at maximum when object closer than near limit. Inverse- Analog output is at maximum when object farther than far limit.
Resp TAU Factor	The sensor can do exponential averaging. The response time is specified as the time for the echo average to reach 95% of actual distance. The response time is $3 * \text{RESP\_TAU\_FACTOR} * \text{CYCLE\_TIME}$ . The TAU factor is limited to powers of 2 (1, 2, 4, 8, 16, 32, 64, 128, and 256). See Exponential Averaging on page 62.
Loss Echo State	Determines if the analog output goes to either minimum or maximum value on echo loss. To specify hold on echo loss, set ECHO LOSS (CYCLES) to 0.
Echo Loss (Cycles)	=0 - On echo loss, the sensor holds the outputs for the last know distance. >0 - When an object is not detected for this many cycles, the sensor sets the output to its LOSS ECHO STATE.
Analog Minimum (Volts or mA)	Determines the minimum analog output value for the sensor. For voltage models this parameter is in volts, and for current models this parameter is in mA. Normally 0 for voltage sensors and 4 mA for current sensors.
Analog Maximum (Volts or mA)	Determines the maximum analog output value for the sensor. For voltage models this parameter is in volts, and for current models this parameter is in mA. Normally 10 volts for voltage sensors and 20 mA for current sensors.

### Advanced Parameters

Model Gain	Used to change the sensitivity of the sensor. Increasing this value increases the distance that an object can be seen. Higher gains can be used to see smaller objects. Increasing the gain however, increases the deadband and can require a longer cycle time. The standard gain is 100.
Cycle Time(usec)	This sensor sends a burst of ultrasonic energy at regular intervals, and listens for the reflection of that ultrasonic energy. This parameter determines the time between bursts of ultrasonic energy. Ultrasonic energy requires 150 microseconds to travel from the sensor face to an object at 254 mm (1 inch) and back to the sensor face.
Ramp Start(in.)	Consult Schneider Electric SCC before changing this field. The ramp decreases the sensitivity of the sensor close to the sensor face where the receive transducer is still ringing from the transmitted energy. This ramp enables a closer deadband value.

Slow Ramp	This parameter must be enabled for high gain sensors. The slow ramp decreases the sensitivity of the sensor farther from the sensor face than the normal ramp. This decreased sensitivity is need to ignore the increase ringing near the sensor face due to the higher gain. If the MODEL GAIN is set greater than 100, then this should be set to YES.
Deadband(in.)	The transmitted ultrasonic energy causes the receive transducer to ring. The deadband is the time for this ringing to diminish to the point where the transducer can receive its echo.
Range Dist(in.)	The farthest distance at which the sensor can detect an object. The SC606A-BV0 and SC606A-BC0 sensors have a maximum range of 279 mm (11 inches) with a maximum far limit of 254 mm (10 inches).
Burst Width(usec)	Consult Schneider Electric SCC before changing this field. Standard value is 18. The ultrasonic transmit power can be lowered by decreasing this value.
Temp Comp	The speed of sound changes with temperature. The sensor can be configured to compensate the receive echo distance for temperature. Since the temperature sensor is internal to the sensor and affected by internal heating, the temperature compensation takes 20 minutes after the sensor is powered to be effective. The standard value is ON.

AA option (Remote Limit Setup) – These models always set the limits at two distinct limits.

## SC900 Configuration Parameters

In the operation of the sensor, the outputs are described as either logically ON or logically OFF. Each output for these sensors has a N.O./N.C. configuration parameter, which determines if logically ON is sinking/sourcing or non-sinking/non-sourcing. If the N.O./N.C. parameter for an output is set to N.O., then that output is sinking/sourcing when that output is logically ON. If the N.O./N.C. parameter for an output is set to N.C., then that output is non-sinking/non-sourcing when that output is logically ON.

The SC900 series sensor's parameters are separated under three tab controls: 1) Limits / Outputs, 2) Other Parameters, and 3) Sensing Parameters. The tab controls appear just below the model description. To switch between tab controls, click the desired tab control. The parameters are explained under the tab control name under which they appear.

Limits / Outputs	Other Parameters	Sensing Parameters
------------------	------------------	--------------------

For help about any configuration parameter, pause the cursor pointer on the parameter field. A popup window appears which explains the configuration parameter.

The definitions of some of the following parameters are explained in more detail in "Sensing Terms" of the Schneider Electric sensors catalog.

The parameters used by the Limits and Outputs section is dependent upon the processing type selected, and in the case of Dual Level processing the outputs are also dependent on the function selected for the outputs.

Proximity processing: Proximity on/off processing with delays. The outputs are logically ON when the object is between limits and are logically OFF when no object is detected between the limits.

Model	SM900A-100000			Processing	Proximity
Desc					

Outputs	NPN/PNP	N.O./N.C.	Pulse Len(Cycles)
Black-wire	NPN	N.O.	0
White-wire	PNP	N.O.	0

Delays		Backgnd/Object	Backgnd
Change On(Cycles)	2		
Change Off(Cycles)	2		



**Proximity NoEcho Processing:** Proximity on/off with delays and no echo processing. This processing is intended for proximity applications where the echo can momentarily be lost due to such things as gusts of air. With this processing mode, the outputs are logically ON when the object is detected between limits and are logical OFF when the object is detected outside the limits. In addition, you can specify the outputs to hold or go to a specified state when echo is lost for Echo Loss (Cycles). With this processing mode, no echo does not reset the on or off delay counters. For example if you have a 1 second on delay, briefly losing the echo does not reset the on delay counter. If Echo Loss (Cycles) is 0, the outputs hold on echo loss, otherwise this is the count of cycles with no echo before the sensor outputs go to the Echo Loss State.

Model	SM900A-XXXXXX		Processing	Proximity NoEcho	
Desc					

Outputs	NPN/PNP	N.O./N.C.	Pulse Len(Cycles)	Echo Loss State
Black-wire	NPN	N.O.	0	Open
White-wire	PNP	N.O.	0	Open

Delays	Backgnd/Object	Backgnd
Change On(Cycles)		2
Change Off(Cycles)		2
	Echo Loss(Cycles)	0

**Dual Level without alarms:** Pump-in or pump-out control on both outputs. Specify this operation by setting the Processing to Dual Level and the both output functions to Pump. In PumpIn mode, the outputs are logically ON when an object is detected beyond the far limit, are logically OFF when an object is detected closer than the near limit, and hold when an object is detected between the limits. In PumpOut mode, the outputs are logically ON when an object is detected closer than the near limit, are logically OFF when an object is detected beyond the far limit, and hold when an object is detected between the limits.

Model	SM902A-110000		Processing	Dual Level	
Desc					

Outputs	NPN/PNP	N.O./N.C.	Function	Echo Loss State
Black-wire	NPN	N.O.	Pump	Open
White-wire	PNP	N.O.	Pump	Open

Echo Valid(Cycles)	5	Pump On Dly(Cycles)	7
Echo Loss(Cycles)	50	Pump Off Dly(Cycles)	7
Averaging(Cycles)	0	PumpIn/PumpOut	PumpIn

Dual Level with one alarm: A pump output and an alarm output is desired. Specify this operation by setting Processing to Dual Level, and then one output to Pump and the other to either Alarm, Under, or Over. An alarm output is logically ON when the object is not in alarm.

Model  Processing

Desc

**Limits / Outputs** | Other Parameters | Sensing Parameters

Target  Deadband  Alarm(in.)  Range

Near(in.)  Far(in.)

Outputs	NPN/PNP	N.O./N.C.	Function	Echo Loss State
Black-wire	<input type="text" value="NPN"/>	<input type="text" value="N.O."/>	<input type="text" value="Pump"/>	<input type="text" value="Open"/>
White-wire	<input type="text" value="NPN"/>	<input type="text" value="N.O."/>	<input type="text" value="Alarm"/>	<input type="text" value="Open"/>

Echo Valid(Cycles)  Pump On Dly(Cycles)  Alarm On Dly(Cycles)

Echo Loss(Cycles)  Pump Off Dly(Cycles)  Alarm Off Dly(Cycles)

Averaging(Cycles)  PumpIn/PumpOut

Dual Level with both alarms: Dual alarm operation. Specify this operation by setting Processing to Dual Level, and then one output function to Under and the other to Over. In Dual Alarm, both outputs are logically ON when the object is not in alarm (between the near and far limits). When the object is closer than the near limit, the Over alarm output is logically OFF; and when the object is farther than the far limit, the Under alarm output is logically OFF.

Model  Processing

Desc

Outputs	NPN/PNP	N.O./N.C.	Function	Echo Loss State
Black-wire	<input type="text" value="NPN"/>	<input type="text" value="N.O."/>	<input type="text" value="Under"/>	<input type="text" value="Open"/>
White-wire	<input type="text" value="NPN"/>	<input type="text" value="N.O."/>	<input type="text" value="Over"/>	<input type="text" value="Open"/>

Echo Valid(Cycles)  Alarm On Dly(Cycles)

Echo Loss(Cycles)  Alarm Off Dly(Cycles)

Averaging(Cycles)

Dual Setpoint processing: Dual Setpoint operation. In Dual Setpoint operation, both the black-and white-wire outputs are logically OFF when object is farther than the far limit, the black-wire output is logically ON when the object is closer than the far limit, and both the black- and white-wire outputs are logically ON when the object is closer than near limit.

Model	SM902A-124000		Processing	Dual Setpoint	
Desc					

Outputs	NPN/PNP	N.O./N.C.	Setpoint	Echo Loss State
Black-wire	NPN	N.O.	Far	Open
White-wire	NPN	N.O.	Near	Open

Echo Valid(Cycles)	5	Near On Dly(Cycles)	10	Far On Dly(Cycles)	10
Echo Loss(Cycles)	66	Near Off Dly(Cycles)	10	Far Off Dly(Cycles)	10
Averaging(Cycles)	0				

#### Non-Tab Control Parameters

Name	Description
Model	The number for the model, which is also the filename for this model. This number can be from 1 to 23 characters long.
Processing	Specifies the model processing. Proximity - Standard proximity processing. Dual Level - Dual Level Latch (PumpIn / PumpOut) no alarm output. - Dual Level Latch (PumpIn/ PumpOut) with alarm output. - Dual Alarms Dual Setpoint - Dual Setpoint operation. Proximity NoEcho – Proximity processing with noecho mode.
Desc	Can be used to document the operation of the sensor.

#### Simulation Window Parameters

Near Limit	Determines the default near limit of the sensor. This parameter can be changed by either dragging this limit with the mouse or typing in a new value. For fine adjustment of limit, click the arrows below the limit. Setting the limits with the pushbutton changes this limit.
Far Limit	Determines the default far limit of the sensor. This parameter can be changed by either dragging this limit with the mouse or typing in a new value. For fine adjustment of limit, click the arrows below the limit. Setting the limits with the pushbutton changes this limit.
Alarm Limit	For Dual Level with Alarm only. Determines the default alarm limit of the sensor. This parameter can be changed by either dragging this limit with the mouse or typing in a new value. For fine adjustment of limit, click the arrows below the limit. Setting the limits with the pushbutton changes this limit (See "Setting Alarm Limit with Pushbutton" topic on page 61.

## Limits and Outputs

Outputs	
NPN/PNP	Selects whether the output is NPN or PNP Select NPN for sinking output. Select PNP for sourcing output.
N.O./N.C.	Select whether output is normally open (N.O.) or normally closed (N.C.). Select N.O. for logical ON to be sinking or sourcing. Select N.C. for logical ON to be non-sinking or non-sourcing.  Proximity - Output logically ON when object between limits and logically OFF when object not between limits. Dual Level (PumpIn) - Output turn logically ON when object beyond far limit and logically OFF when object closer than near limit. Dual Level (PumpOut) - Output turns logically ON when object closer than near limit and logically OFF when object beyond far limit. Dual Level Pump with 1 alarm. Alarm output logically ON when object not in alarm. Dual Level Alarm: Output logically ON when not in alarm. Over alarm output logically ON when object farther than near limit. Under alarm output logically ON when object closer than far limit Dual Level Setpoint: Black-wire output turns logically ON when object closer than far limit. White-wire output turns logically On when object closer than near limit.

## Proximity Processing

Pulse Len(Cycles)	Set to zero for an output that is logically ON when object between limits and logically OFF when object not between limits. Set non-zero for a retriggerable logically ON output pulse of this many cycles when object moves to between the object. The output remains on this many cycles even if the object moves from between the limits. A retriggerable means the pulse timer is reset every time the object moves between the limits. See "Proximity Pulse Length" topic on page 63.
Delays	
Change On (Cycles)	The number of consecutive cycles the object has to be detected between limits before the outputs change to the logical ON state.
Change Off(Cycles)	The number of consecutive cycles no object can be detected between the limits before the outputs change to the logical OFF state.
Backgnd/Object	Select Backgnd or Object sensing mode: Backgnd - Sensor processes only first echo detected (standard setting) Object - Sensor processes multiple echoes and assumes object is between limits if any echo is detected between limits.

### Proximity NoEcho Processing

Pulse Len(Cycles)	Set to zero for an output that is logically ON when object between limits and logically OFF when object not between limits. Set non-zero for a retriggerable logically ON output pulse of this many cycles when object moves to between the object. The output remains on this many cycles even if the object moves from between the limits. A retriggerable means the pulse timer is reset every time the object moves between the limits. See "Proximity Pulse Length" topic on page 63.
Loss Echo State	If the sensor loses the object echo, the output can be selected to either open or close the output after ECHO LOSS (CYCLES). To specify hold on echo loss, set ECHO LOSS (CYCLES) parameter to 0. For normally open outputs, the loss echo state is usually open; and for normally closed outputs, the loss echo state is usually closed. Open - On echo loss, the output is non-sinking/non-sourcing. Close - On echo loss, the output is sinking/sourcing.
Delays	
Change On (Cycles)	The number of consecutive cycles the object has to be detected between limits before the outputs change to the logical ON state.
Change Off(Cycles)	The number of consecutive cycles the object is detected outside the limits before the outputs change to the logical OFF state.
Backgnd/Object	Select Backgnd or Object sensing mode: Backgnd - Sensor processes only first echo detected (standard setting) Object - Sensor processes multiple echoes and assumes object is between limits if any echo is detected between limits.
Echo Loss (Cycles)	=0 - On echo loss, the sensor holds the outputs for the last known distance >0 - When an object is not detected for this many cycles, the sensor sets the output to its LOSS ECHO STATE.

### Dual Level (Pump, Alarm, and Setpoint)

Loss Echo State	If the sensor loses the object echo, the output can be selected to either open or close the output after ECHO LOSS (CYCLES). To specify hold on echo loss, set ECHO LOSS (CYCLES) parameter to 0. For normally open outputs, the loss echo state is usually open; and for normally closed outputs, the loss echo state is usually closed. Open - On echo loss, the output is non-sinking/non-sourcing. Close - On echo loss, the output is sinking/sourcing.
Echo Valid (Cycles)	After a echo loss condition, the sensor needs this many valid cycles to resume echo processing.
Echo Loss (Cycles)	=0 – On echo loss, sensor holds the outputs for the last known distance. >0 - When an object is not detected for this many cycles, the sensor sets the output to its LOSS ECHO STATE.
Averaging (Cycles)	Besides doing delays, the sensor can also do exponential averaging. The value in this field is the number of cycles for echo average distance to reach 95% of actual distance. See Exponential Averaging on page 62.

Dual Level (Pump only or Pump with Alarm)

Function	<p>Selects the function for this output.</p> <p>Pump - The output is a pump control output. The operation depends upon the PumpIn/PumpOut parameter.</p> <p>Alarm - The output is an alarm output. If the alarm limit is closer than midpoint between near and far limits, the alarm output is an over alarm. If the alarm output is farther than midpoint between the near and far limits, the output is an under alarm.</p> <p>Over - The output is an over alarm output. The output is logically ON when the object is farther than the alarm limit.</p> <p>Under - The output is an under alarm output. The output is logically ON when the object is closer than the alarm limit</p>
Pump On Dly(Cycles)	<p>PumpIn - number of consecutive cycles object has to be detected farther than far limit to logically turn output ON.</p> <p>PumpOut - number of consecutive cycles object has to be detected closer than near limit to logically turn output ON.</p>
Pump Off Dly(Cycles)	<p>PumpIn - number of consecutive cycles object has to be detected closer than near limit to logically turn output OFF.</p> <p>PumpOut - number of consecutive cycles object has to be detected farther than far limit to logically turn output OFF.</p>
Alarm On Dly(Cycles)	<p>Over Alarm - number of consecutive cycles object has to be detected closer than near limit for output to logically turn OFF.</p> <p>Under Alarm - number of consecutive cycles object has to be detected farther than far limit for output to logically turn ON.</p>
Alarm Off Dly(Cycles)	<p>Over Alarm - number of consecutive cycles object has to be detected farther than near limit for output to logically turn ON.</p> <p>Under Alarm - number of consecutive cycles object has to be detected closer farther than far limit for output to logically turn OFF</p>
PumpIn/PumpOut	<p>PumpIn - Output turns logically ON when object farther than far limit and logically OFF when object closer than near limit.</p> <p>PumpOut - Output turns logically ON when object closer than near limit and logically OFF when object farther than far limit.</p>

### Dual Level - Both Alarms

Function	Selects the function for this output. Over - The output is an over alarm output. The output is logically ON when the object is farther than the alarm limit. Under - The output is an under alarm output. The output is logically ON when the object is closer than the alarm limit
Alarm On Dly(Cycles)	Over Alarm - number of consecutive cycles object has to be detected closer than near limit for output to logically turn OFF. Under Alarm - number of consecutive cycles object has to be detected farther than far limit for output to logically turn ON.
Alarm Off Dly(Cycles)	Over Alarm - number of consecutive cycles object has to be detected farther than near limit for output to logically turn ON. Under Alarm - number of consecutive cycles object has to be detected closer farther than far limit for output to logically turn OFF

### Dual Setpoint

Near On (Cycles)	The number of consecutive cycles the object has to be detected closer than the near limit for the near output to turn logically ON.
Near Off (Cycles)	The number of consecutive cycles the object has to be detected farther than the near limit for the near output to turn logically OFF.
Far On (Cycles)	The number of consecutive cycles the object has to be detected closer than the far limit for the far output to turn logically ON.
Near On (Cycles)	The number of consecutive cycles the object has to be detected farther than the far limit for the far output to turn logically OFF.

### Other Parameters

Pushbutton Limits Setup Offsets	
From One Target Distance	When the limits pushbutton is pressed twice on a single target, the near and far limits are offset from that single target distance by these distances.
From Two Target Distances	When the limits pushbutton is pressed once on one target and then on another target, the limits are offset from the two targets by these distances.

Echo Suppression	
Ignore Near ActionMode	<p>Selects near echo suppression mode:</p> <p>Disabled - Near echoes are not ignored.</p> <p>Ignore Farther Echoes - If an echo is detected before the IGNORE NEAR LIMIT, then all farther echoes are ignored and echo processing is skipped this cycle.</p> <p>Use Farther Echoes - Ignores echoes before IGNORE NEAR LIMIT, but processes farther echoes. If echo detected closer than IGNORE NEAR LIMIT and no other echoes detected this cycle, then echo processing is skipped this cycle.</p>
Ignore Near DistanceMode	<p>Specifies how to interpret the IGNORE NEAR DISTANCE parameter. Relative is from the near limit and absolute is from the sensor face.</p> <p>Relative - <math>\text{IGNORE NEAR LIMIT} = \text{NEAR LIMIT} - \text{IGNORE NEAR DISTANCE}</math></p> <p>Absolute - <math>\text{IGNORE NEAR LIMIT} = \text{IGNORE NEAR DISTANCE}</math></p>
Ignore Near Distance	See IGNORE NEAR DISTANCE MODE
Ignore Far Action Mode	<p>Selects far echo suppression mode:</p> <p>Disabled - Far echoes are not ignored;</p> <p>No Echo - Echoes beyond IGNORE FAR LIMIT are processed as no echoes</p> <p>Ignore - Echoes beyond IGNORE FAR LIMIT are ignored, echo processing is skipped this cycle.</p>
Ignore Far DistanceMode	<p>Specifies how to interpret the ignore far distance parameter. Relative is from the far limit and absolute is from the sensor face.</p> <p>Relative - <math>\text{IGNORE FAR LIMIT} = \text{FAR LIMIT} + \text{IGNORE FAR DISTANCE}</math></p> <p>Absolute - <math>\text{IGNORE FAR LIMIT} = \text{IGNORE FAR DISTANCE}</math></p>
Ignore Far Distance	See IGNORE FAR DISTANCE MODE
Limit Pushbutton Armed/Enable(Secs)	This parameter enables the 3 seconds that the limit pushbutton must be pressed to enable limit setting. Set to 0 to have the limit pushbutton always armed. Set to -1 to disable limit setting with the limit pushbutton.
Limit Setting Timeout(Secs)	After setting the first limit or arming limits, the next limit must be set within this time, or the limits revert back to the previous limit settings.
Hysteresis	Hysteresis is used to prevent the outputs from oscillating on and off when the object is at one of the limits.
Near Limit	<p><u>Proximity</u>: When object is detected farther than the near limit, the near limit is moved this distance closer to the sensor.</p> <p><u>Dual Level Pump</u>: Outputs unaffected. After multicolor LED turns red, keeps multicolor LED red this distance beyond near limit.</p> <p><u>Dual Level Alarm</u>: Holds alarm output this distance beyond near/alarm limit.</p> <p><u>Dual Setpoint</u>: Holds near output state this distance beyond near limit.</p>
Far Limit	<p><u>Proximity</u>: When object is detected closer than the far limit, the far limit is moved this distance farther from sensor, which prevents output oscillation.</p> <p><u>Dual Level Pump</u>: Outputs unaffected. After multicolor LED turns amber, keeps multicolor LED amber this distance closer than far limit.</p> <p><u>Dual Level Alarm</u>: Outputs unaffected. Keeps multicolor LED amber this distance closer than far/alarm limit.</p> <p><u>Dual Setpoint</u>: Holds far output state this distance closer than far limit.</p>



Hrwd Hyst	For Proximity processing only. This is used to "lock" the sensor onto a small object by lowering the echo detection threshold. If this parameter is set to enabled and the object is between the limits, the hardware hysteresis is applied.
Settable Delays	For Proximity processing only. The limit pushbutton can be used to change the delays. No: The delays cannot be changed with the Limit pushbutton. Period: The delay is determined by the interval of time the pushbutton is pressed Cycles: Each press of the pushbutton increases the delay by the number of cycles specified by the next parameter. See "Setting Delays with Pushbutton" topic on page 61 for instruction on how to set the delays with the pushbutton.
Delay Interval (Cycles)	For Proximity processing with Settable Delays set to Cycles. Specifies the number of cycles each press of pushbutton increases delay.

Sensing Parameters should normally not be changed unless specified by Schneider Electric.

Cycle Time(msec)	This sensor sends a burst of ultrasonic energy at regular intervals, and listens for the reflection of that ultrasonic energy. This parameter determines the time between bursts of ultrasonic energy. 1-meter models standard value is 10.0 2-meter models standard value is 15.0 8-meter models standard value is 100.0
Far Range	Determines the far range of the sensor
Start Ramp	Consult Schneider Electric SCC before changing this field. The Ramp is used to decrease the sensitivity of the sensor close to the sensor face where the receive oscillator is still ringing from the transmitted energy. This allows a closer deadband value. The Start Ramp is set based upon Xmit Power
Rcvr Gain	Determines the transducer receiver gain. Set to 100 for 1- and 2-meters models and set to 200 for 8-meter models.
NormPwr Deadband	The transmitted ultrasonic energy causes the receive transducer to ring. The deadband is the time for this ringing to diminish to the point where the transducer can receive its echo. This is the normally used deadband.
LowPwr Deadband	Set to 0. (See dual power mode on page 62)
NormPwr Burst Cnt	The number of times the transmitter transducer is stimulated. Increasing this count increases the transmitter power. Do not increase this value over 16.
LowPwr Burst Cnt	Set to 0. (See dual power mode on page 62)
Hold LowPwr	Set to 0. (See dual power mode on page 62)
Snub On (Usec) (8 Meter Only)	Set to 250 usec
Xmit Power (1 & 2 Meter Only)	For Documentation only. Set to NORM for 1-meter models and set to HIGH for 2-meter models.

Min Echo Width	Sometimes noise can be ignored by accepting only echoes that are present for some duration. Accept first echo wider than this width. If early echo less than this width and later echo wider than this width, use later echo. If all echoes are less than this width, use the last echo.
Gap Fill Width	Set to 0. 0=disable. Fill gap between echoes if less than this number of usec. Used to prevent break up of an echo from causing an echo in the window.
Echo Duration Logic(UseC)	Set to 0. 0= disable. Use first echo wider than this, else use widest echo.

## SC906 Configuration Parameters

The SC906 series sensor's parameters are separated under three tab controls: 1) Limits / Outputs, 2) Other Parameters, and 3) Sensing Parameters. The tab controls appear just below the model description. To switch between tab controls, click the desired tab control. The parameters are explained under the tab control name under which they appear.

For help about any configuration parameter, pause the cursor pointer on the parameter field. A popup window appears which explains the configuration parameter.

The definitions of some of the following parameters are explained in more detail in "Sensing Terms" of the Schneider Electric sensors catalog.

### Non-Tab Control Parameters

Name	Description
Model	The number for the model, which is also the filename for this model. This number can be from 1 to 23 characters long.
Current/Voltage	Documentation field that shows if this configuration is for CURRENT or VOLTAGE analog output. This parameter must match the hardware capabilities of the sensor. Before downloading a configuration to a sensor, the program verifies that the sensor hardware matches the current or voltage selection.
Desc	Can be used to document the operation of the sensor.

### Simulation Window Parameters

Near Limit	Determines the default near limit of the sensor. This parameter can be changed by either dragging this limit with the mouse or typing in a new value. For fine adjustment of limit, click the arrows below the limit. Setting the limits with the pushbutton changes this limit.
Far Limit	Determines the default far limit of the sensor. This parameter can be changed by either dragging this limit with the mouse or typing in a new value. For fine adjustment of limit, click the arrows below the limit. Setting the limits with the pushbutton changes this limit.

### Limits / Outputs Parameters

Direct/Inverse	Specifies DIRECT or INVERSE operation. DIRECT - The analog output is at maximum when object at or closer than near limit. INVERSE - The analog output is at maximum when object is at or farther than far limit. AUTO – The analog output is at minimum when object is at first limit set and at maximum when object at second limit set.
First Limit Set	In Auto mode, determines which limit was set first, and thus which limit the analog output is at a minimum. This parameter is overwritten when the limits are taught.
Averaging	Specifies the number of cycles for the echo average to reach 95 % of actual distance. 1 and 2 are special cases. If 1 is specified, the echo average is set to the last echo value. If 2 is specified, then the echo is the average of the last 2 cycles. Otherwise the program does exponential averaging of the distance. See Exponential Averaging on page 62.
Echo Loss (Cycles)	If echo not detected for this many cycles, output goes to state specified by LOSS ECHO STATE. Set to 0 to hold on echo loss.
Loss Echo State	Select either MIN or MAX. Specifies power-up and echo loss state for output. For hold on echo loss set ECHO LOSS (CYCLES) to 0.
Echo Valid (Cycles)	After a echo loss, the output is not updated until this many valid echoes are detected.
Analog Minimum	Specifies minimum current or voltage value.
Analog Maximum	Specifies maximum current or voltage value.

### Other Parameters

Pushbutton Setup Limits Offsets	
From One Target Distance	When the limits pushbutton is pressed twice on a single target, the near and far limits are offset from that single target distance by these distances
From Two Target Distances	When the limits pushbutton is pressed once on one target and then on another target, the limits are offset from the two targets by these distances.

Echo Suppression	
Ignore Near ActionMode	<p>Selects near echo suppression mode:</p> <p>Disabled - Near echoes are not ignored.</p> <p>Ignore Farther Echoes - If an echo is detected before the IGNORE NEAR LIMIT, then all farther echoes are ignored and echo processing is skipped this cycle.</p> <p>Use Farther Echoes - Ignores echoes before IGNORE NEAR LIMIT, but processes farther echoes. If echo is detected closer than IGNORE NEAR LIMIT and no other echoes detected this cycle, then echo processing is skipped this cycle.</p>
Ignore Near: DistanceMode	<p>Specifies how to interpret the IGNORE NEAR DISTANCE parameter. Relative is from the near limit and absolute is from the sensor face.</p> <p>Relative - <math>\text{IGNORE NEAR LIMIT} = \text{NEAR LIMIT} - \text{IGNORE NEAR DISTANCE}</math></p> <p>Absolute - <math>\text{IGNORE NEAR LIMIT} = \text{IGNORE NEAR DISTANCE}</math></p>
Ignore Near: Distance	See IGNORE NEAR DISTANCE MODE
Ignore Far Action Mode	<p>Selects far echo suppression mode:</p> <p>Disabled - Far echoes are not ignored;</p> <p>No Echo - Echoes beyond IGNORE FAR LIMIT are processed as no echoes</p> <p>Ignore - Echoes beyond IGNORE FAR LIMIT are ignored, echo processing is skipped this cycle.</p>
Ignore Far DistanceMode	<p>Specifies how to interpret the ignore far distance parameter. Relative is from the far limit and absolute is from the sensor face.</p> <p>Relative - <math>\text{IGNORE FAR LIMIT} = \text{FAR LIMIT} + \text{IGNORE FAR DISTANCE}</math></p> <p>Absolute - <math>\text{IGNORE FAR LIMIT} = \text{IGNORE FAR DISTANCE}</math></p>
Ignore Far Distance	See IGNORE FAR DISTANCE MODE
Limit Pushbutton Armed/Enable(Secs)	This parameter sets the standard 3 seconds that the limit pushbutton must be pressed to enable limit setting. Set to 0 to have the limit pushbutton always armed. Set to -1 to disable limit setting with the limit pushbutton.
Limit Setting Timeout(Secs)	After setting the first limit or arming limits, the next limit must be set within this time, or the limits revert back to the previous limit settings.
M-LED Hysteresis	Multicolor LED hysteresis applies hysteresis of this distance to the multicolor LED to prevent the multicolor LED from oscillating at the limit boundaries.
Teachable Analog Response	Enables teaching the Analog Response with the limit pushbutton. See section “SM906 – Teaching Analog Response”.

Sensing Parameters should normally not be changed unless specified by Schneider Electric.

Cycle Time(msec)	<p>This sensor sends a burst of ultrasonic energy at regular intervals, and listens for the reflection of that ultrasonic energy. This parameter determines the time between bursts of ultrasonic energy.</p> <p>1-meter models standard value is 10.0</p> <p>2-meter models standard value is 15.0</p> <p>8-meter models standard value is 100.0</p>
Far Range	Determines the far range of the sensor

Start Ramp	Consult Schneider Electric SCC before changing this field. The Ramp is used to decrease the sensitivity of the sensor close to the sensor face where the receive oscillator is still ringing from the transmitted energy. This allows a closer deadband value. The Start Ramp is set based upon Xmit Power.
Rcvr Gain	Determines the transducer receiver gain. Set to 100 for 1- and 2-meters models and set to 200 for 8-meter models.
NormPwr Deadband	The transmitted ultrasonic energy causes the receive transducer to ring. The deadband is the time for this ringing to diminish to the point where the transducer can receive its echo. This is the deadband that is normally used.
LowPwr Deadband	Set to 0. (See dual power mode on page 62)
NormPwr Burst Cnt	The number of times the transmitter transducer is stimulated. Increasing this count increases the transmitter power. Do not increase this value over 16.
LowPwr Burst Cnt	Set to 0. (See dual power mode on page 62)
Hold LowPwr	Set to 0. (See dual power mode on page 62)
Snub On (Usec) (8 Meter Only)	Set to 250 usec
Xmit Power (1 & 2 Meter Only)	For documentation only. Set to NORM for 1-meter models and set to HIGH for 2-meter models.
Min Echo Width	Sometimes noise can be ignored by accepting only echoes that are present for some duration. Accept first echo wider than this width. If early echo less than this width and later echo wider than this width, use later echo. If all echoes are less than this width, use the last echo.
Gap Fill Width	Set to 0. 0=disable. Fill gap between echoes if less than this number of usec. Used to prevent break up of an echo from causing an echo in the window.
Echo Duration Logic(Usec)	Set to 0. 0=disable. Use first echo wider than this, else use widest echo.
Plus Fault Hld Cnt	Set to 0. (See Sliding Valid Window below)
Plus Delta Dist(Cnts)	Set to 0. (See Sliding Valid Window below)
Plus Slack Dist(Cnts)	Set to 0. (See Sliding Valid Window below)
Plus Fault On Cnt	Set to 0. (See Sliding Valid Window below)

## VC1-N / VC18-N and VC1-P / VC18-P Discrete Configuration Parameters

### Introduction

The functionality and operation of the VC18 sensors is exactly like the corresponding VC1 sensor. The only difference is the sensor housing.

The VC1-N sensors have a black-wire NPN output.

The VC1-P sensors have a black-wire PNP output.

The VC1 Discrete sensor's parameters are separated under three tab controls: 1) Limits / Output, 2) Other Parameters, and 3) Sensing Parameters. The tab controls appear just below the model description. To switch between tab controls, click the desired tab control. The parameters are explained under the tab control name under which they appear.

**Limits / Output** | **Other Parameters** | **Sensing Parameters**

For help about any configuration parameter, pause the cursor pointer on the parameter field. A popup window appears which explains the configuration parameter.

The definitions of some of the fields are explained in more detail in "Sensing Terms" of the Schneider Electric sensors catalog.

The VC1 Discrete sensors support both Proximity and Dual-Level processing. The parameters presented are determined by the selected processing mode.

**Proximity Processing:** Used for proximity on/off processing with delays. The outputs switch to one state when the object is between the limits and to the opposite state when no object is detected between the limits.

The screenshot displays the configuration interface for a VC1 Discrete sensor. At the top, the 'Model' field is set to 'VMI-PNO-00' and the 'Processing' mode is set to 'Proximity'. Below this is a 'Desc' field. The interface features three tabs: 'Limits / Output' (selected), 'Other Parameters', and 'Sensing Parameters'. The 'Limits / Output' tab contains several parameters: 'Target' (0.000), 'Deadband' (1.875), 'Range' (22.500), 'Near (in.)' (2.000), and 'Far (in.)' (20.000). A 'status' indicator shows a green circle. A 'Reset' button is located to the right of the 'Range' field. Below these parameters, there are three output settings: 'Zone' (set to 'On'), 'Within' (set to 'Off'), and 'Outside' (set to 'Off'). A 'Power Up' section shows 'Change (Cycles)' set to 2. At the bottom, the 'Backgnd/Object' field is set to 'Backgnd'.

**Dual-Level Processing:** Typically used for dual-level latch (Pump In and Pump Out) operation, where the output switches to one state when the object is closer than the near limit and to the opposite state when the object is farther than the far limit. Dual level processing has four zones, where the action for each output can be specified by zone. The four zones are: 1) between deadband and near limit, 2) between near and far limit, 3) between far limit and far range, and 4) echo loss.

Model: WML-PP000000 Processing: Dual Level

Desc:

**Limits / Output** | **Other Parameters** | **Sensing Parameters**

Target: 0.000

Deadband: 1.875

Range: 22.500

status:

V+ PNP

Near (in.): 3.000

Far (in.): 20.000

Reset

Zone: Near Within Far Echo Loss Power Up

Output: On No Chng Off Off Off

Change (Cycles): 30 2 30 200

Backgnd/Object: Backgnd

### Non-Tab Control Parameters

Name	Description
Model	The number for the model, which is also the filename for this model. This number can be from 1 to 14 characters long.
Processing	Specifies the model processing. Select either Proximity or Dual Level.
Desc	A comment field that can be used to describe the model operation or any other useful information.

### Simulation Window Parameters

Near Limit(in.)	Determines the near limit of the sensor. This parameter can be changed by either dragging the limit with the mouse or typing in a limit value. For fine adjustment of limit, click the arrows below the limit.
Far Limit(in.)	Determines the far limit of the sensor. This parameter can be changed by either dragging the limit with the mouse or typing in a limit value. For fine adjustment of limit, click the arrows below the limit.



### Limits and Outputs - Proximity

Zone	Within	Outside	Power Up
Output	<input type="text" value="On"/>	<input type="text" value="Off"/>	<input type="text" value="Off"/>
Change (Cycles)	<input type="text" value="2"/>	<input type="text" value="2"/>	
Backgnd/Object	<input type="text" value="Backgnd"/>		

The proximity processing defines two zones: 1) Within - object is between the limits, and 2) Outside - no object is between the limits. The number of consecutive echoes required in a zone to switch to that zone is specified by the CHANGE(CYCLE) parameter for each zone. The action for the output can be set to OFF, ON, NO CHNG. Also the power up state of the output can be specified, which means the output is in this state until an object is in a known zone.

Backgnd/Object	Selects either Backgnd or Object mode processing Backgnd - Sensor processes only first echo detected (standard). Object - Sensor processes multiple echoes and uses the first echo detected farther than the near limit. If no echo is detected farther than the near limit, then the sensor uses the farthest echo detected.
----------------	---

### Limits and Outputs - Dual Level

Zone	Near	Within	Far	Echo Loss	Power Up
Output	<input type="text" value="On"/>	<input type="text" value="No Chng"/>	<input type="text" value="Off"/>	<input type="text" value="Off"/>	<input type="text" value="Off"/>
Change (Cycles)	<input type="text" value="30"/>	<input type="text" value="2"/>	<input type="text" value="30"/>	<input type="text" value="200"/>	
Backgnd/Object	<input type="text" value="Backgnd"/>				

The dual-level processing defines four zones: 1) Near - object is closer than near limit, 2) Within - object is between the limits, 3) Far - object between far limit and far range, 4) Echo Loss - no object detected (echo loss). The number of consecutive echo required to switch to a zone is specifies by the CHANGE(CYCLE) parameter for each zone. The action for the PNP output can be set to OFF, ON, or NO CHNG. Also the power up state the output can be specified, which means the output is in this state until an object is in a known zone.

For Pump-In operation, set Near = OFF, Within = NO CHNG, and Far = ON.

For Pump-Out operation, set Near = ON, Within = NO CHNG, and Far = OFF.

Backgnd/Object	Selects either Backgnd or Object mode processing Backgnd - Sensor processes only first echo detected (standard). Object - Sensor processes multiple echoes, and uses first echo detected farther than near limit. If no echo detected farther than near limit, then uses farthest echo received.
----------------	--

### Other Parameters

Limit Setup Double Press Offsets Near and Far	After the limits are armed and the limits pushbutton is pressed twice within 1 second on a single target, the near and far limits are offset from that single target distance by these distances.
Limit Pushbutton Armed/Enable(Secs)	Determines the number of seconds the pushbutton must be pressed to arm limit setting (0 for immediate arming). Set to -1 to disable limit setting with the limit pushbutton. Standard value is 3 seconds.
Limit Setting Timeout(Secs)	After setting the first limit or arming limits, the next limit must be set within this time, or the limits revert back to the previous limit settings.
<b>Echo Suppression</b>	
Ignore Near ActionMode	Selects near echo suppression mode: Disabled - Near echoes are not ignored. Ignore Farther Echoes - If an echo is detected before the IGNORE NEAR LIMIT, then all farther echoes are ignored and echo processing is skipped this cycle. Use Farther Echoes - Ignores echoes before IGNORE NEAR LIMIT, but processes farther echoes. If echo is detected closer than IGNORE NEAR LIMIT and no other echoes detected this cycle, then echo processing is skipped this cycle.
Ignore Near: Distance	Distance closer than near limit to ignore echoes.
Ignore Far Action Mode	Selects far echo suppression mode: Disabled - Far echoes are not ignored; No Echo - Echoes beyond IGNORE FAR LIMIT are processed as no echoes Ignore - Echoes beyond IGNORE FAR LIMIT are ignored, echo processing is skipped this cycle.
Ignore Far Distance	Distance farther than far limit to ignore echoes.

### Sensing Parameters

The sensing parameters should normally not be changed.

Cycle Time(usec)	This sensor sends a burst of ultrasonic energy at regular intervals, and listens for the reflection of that ultrasonic energy. This parameter determines the time between bursts of ultrasonic energy. Ultrasonic energy requires 150 microseconds to travel from the sensor face to an object at 25.4 mm (1 inch) and back to the sensor face.
Ramp/Deadband (in.)	Consult Schneider Electric SCC before changing this field. The Ramp/Deadband is used to decrease the sensitivity of the sensor close to the sensor face where the receive transducer is still ringing from the transmitted energy. The echo detect receiver is enabled at this time.

Burst Count	Consult Schneider Electric SCC before changing this field. Standard value is 4. The ultrasonic transmit power can be lowered by decreasing this value.
Range Dist(in.)	Determines how far the sensor continues to listen for echoes
Near Limit Hyst(in.) (Proximity only)	When an object is detected within the limits, the sensor moves the near limit this much closer to the sensor to prevent output oscillation at the near limit.
Far Limit Hyst(in.) (Proximity only)	When an object is detected within the limits, the sensor moves the far limit this much farther from the sensor to prevent output oscillation at the far limit.
Ramp Hyst (Proximity only)	When an object is detected between the near and far limits, the sensor can optionally lower the threshold detection level by starting the ramp earlier. This lowering of the threshold can "lock" the sensor onto a small object which is barely detectable. This lowering of the threshold causes the object to appear closer, which can prevent output oscillation at the far limit; but can cause output oscillation at near limit (see next parameter).
Hrdwr Hyst Off(in.) (Proximity only)	As mentioned in the previous parameter, the lowering of the echo detection threshold causes the object to appear closer. At the near limit, this causes oscillation if the distance "shift" due to lowering the threshold causes the object to appear closer than the near limit. The hardware hysteresis is turned off when an object is detected within this distance of near limit.

## VC1-C / VC18-C and VC1-V / VC18-V Analog Configuration Parameters

### Introduction

The functionality and operation of the VC18 sensors is exactly like the corresponding VC1 sensor. The only difference is the sensor housing.

The VC1-C sensors have a black-wire 0-20 mA Analog output.  
The VC1-V sensors have a black-wire 0-10 volt Analog output.

The VC1 Analog series sensor's parameters are separated under three tab controls: 1) Limits / Output, 2) Other Parameters, and 3) Sensing Parameters. The tab controls appear just below the model description. To switch between tab controls, click the desired tab control. The parameters are explained under the tab control name under which they appear.

**Limits / Output** | **Other Parameters** | **Sensing Parameters**

For help about any configuration parameter, pause the cursor pointer on the parameter field. A popup window appears which explains the configuration parameter.

The definitions of some of the fields are explained in more detail in "Sensing Terms" of the Schneider Electric sensors catalog.

The screenshot displays the configuration interface for a VC1 Analog sensor, specifically the 'Limits / Output' tab. The interface includes the following elements:

- Model:** VMI-VA0000
- Current/Voltage:** Voltage (dropdown menu)
- Desc:** (empty text field)
- Tab Controls:** Limits / Output | Other Parameters | Sensing Parameters
- Target:** 13.488 (with three indicator lights: yellow, white, and orange)
- Deadband:** 1.875 (with a blue bar graph and a value of 2.000 below it)
- Range:** 22.500 (with a value of 20.000 below it)
- Reset:** (button)
- Auto/Inverse/Direct:** Auto (dropdown menu)
- First Limit Set:** Near (dropdown menu)
- Resp Tau Factor:** 4 (dropdown menu)
- Response:** 60 msec
- Loss Echo State:** Minimum (dropdown menu)
- Echo Loss (Cycles):** 50
- Echo Valid(Cycles):** 2 (dropdown menu)
- Analog Minimum(Volts):** 0.00
- Analog Maximum(Volts):** 10.00

A diagram shows a horizontal line with a green vertical bar in the center, representing the sensor's output range and limits.

### Non-Tab Control Parameters

<u>Name</u>	<u>Description</u>
Model	The number for the model, which is also the filename for this model. This number can be from 1 to 14 characters long.
Current/Voltage	Documentation field that shows whether this configuration is for a CURRENT or VOLTAGE analog output sensor. This parameter must match the hardware capabilities of the sensor. Before downloading a configuration to a sensor, the program verifies that the sensor hardware matches the current or voltage value.
Desc	A comment field that can be used to describe the model operation or any other useful information.

### Simulation Window Parameters

Near Limit(in.)	Determines the near limit of the sensor. This parameter can be changed by either dragging the limit with the mouse or typing in a limit value. For fine adjustment of limit, click the arrows below the limit.
Far Limit(in.)	Determines the far limit of the sensor. This parameter can be changed by either dragging the limit with the mouse or typing in a limit value. For fine adjustment of limit, click the arrows below the limit.

### Limits and Output

Auto/Inverse/Direct	Auto     Analog output is at minimum at first limit set and maximum at second limit set. Inverse     Analog output is at maximum when object farther than far limit. Direct     Analog output is at maximum when object closer than near limit.
First Limit Set	In Auto mode, determines which limit was set first, and thus which limit the analog output is at a minimum. This parameter is overwritten when the limits are taught.
Resp TAU Factor	The sensor can do exponential averaging. The response time is specified as the time for the echo average to reach 95% of actual distance. The response time is $3 * \text{RESP\_TAU\_FACTOR} * \text{CYCLE\_TIME}$ . The TAU factor is limited to powers of 2 (1, 2, 4, 8, 16, 32, 64, 128, and 256). See Exponential Averaging on page 62
Echo Loss State	Determines if the analog output goes to either minimum or maximum value on echo loss. To specify hold on echo loss, set ECHO LOSS (CYCLES) to 0.
Echo Loss (Cycles)	=0 - On echo loss, the sensor holds the outputs for the last know distance. >0 - When an object is not detected for this many cycles, the sensor sets the output to its LOSS ECHO STATE.
Echo Valid (Cycles)	After loss-of-echo, the output is not updated until this many valid echoes are detected.

### Other Parameters

Limit Pushbutton Armed/Enable(Secs)	Determines the number of seconds the pushbutton must be pressed to arm limit setting (0 for immediate arming). Set to -1 to disable limit setting with the limit pushbutton. Standard value is 3 seconds.
Limit Setting Timeout(Secs)	After setting the first limit or arming limits, the next limit must be set within this time, or the limits revert back to the previous limit settings.
<b>Echo Suppression</b>	
Ignore Near ActionMode	Selects near echo suppression mode: Disabled - Near echoes are not ignored. Ignore Farther Echoes - If an echo is detected before the IGNORE NEAR LIMIT, then all farther echoes are ignored and echo processing is skipped this cycle. Use Farther Echoes - Ignores echoes before IGNORE NEAR LIMIT, but processes farther echoes. If echo is detected closer than IGNORE NEAR LIMIT and no other echoes detected this cycle, then echo processing is skipped this cycle.
Ignore Near: Distance	Distance closer than near limit to ignore echoes,
Ignore Far Action Mode	Selects far echo suppression mode: Disabled - Far echoes are not ignored; No Echo - Echoes beyond IGNORE FAR LIMIT are processed as no echoes Ignore - Echoes beyond IGNORE FAR LIMIT are ignored, echo processing is skipped this cycle.
Ignore Far Distance	Distance farther than far limit to ignore echoes.

### Sensing Parameters

The sensing parameters should normally not be changed.

Cycle Time(usec)	This sensor sends a burst of ultrasonic energy at regular intervals, and listens for the reflection of that ultrasonic energy. This parameter determines the time between bursts of ultrasonic energy. Ultrasonic energy requires 150 microseconds to travel from the sensor face to an object at 25.4 mm (1 inch) and back to the sensor face.
Ramp/Deadband(in.)	Consult Schneider Electric SCC before changing this field. The Ramp/Deadband is used to decrease the sensitivity of the sensor close to the sensor face where the receive transducer is still ringing from the transmitted energy. The echo detect receiver is enabled at this time.
Burst Count	Consult Schneider Electric SCC before changing this field. Standard value is 4. The ultrasonic transmit power can be lowered by decreasing this value.
Range Dist(in.)	Determines how far the sensor continues to listen for echoes

Temp Comp	The speed of sound changes with temperature. The sensor can be configured to compensate the receive echo distance for temperature. Since the temperature sensor is internal to the sensor and affected by internal heating, the temperature compensation takes 20 minutes after the sensor is powered to be effective. The standard value is ON.
-----------	--

## Other Topics

### SM906 - Sliding Valid Window

The SC906 sensor can ignore echoes that are not within a sliding window moving away from sensor. This may be useful if the main object becomes tilted and the echo bounces off this object off another object and then back to the sensor giving a false distance. The sliding window processing assumes the object cannot move faster away from the sensor than the PLUS DELTA DIST (CNTS) each cycle. Closer echoes are always processed. Each cycle that an echo is not present the sliding window distance is increased PLUS DELTA DIST. If an echo is not detected within this sliding window distance within PLUS FAULT ON CNT, the analog output goes to the LossEchoState value for PLUS FAULT HLD CNT cycles to indicate an error. The new echo distance is compared to the exponential average, which means the PLUS DELTA DIST must compensate for this change which is slower than the actual allowed distance change.

<u>Parameter</u>	<u>Description</u>
Plus Delta Dist (Cnts)	The additional distance to add to the sliding window each cycle. For 1 and 2 meter, 25.4 mm (1 inch) = 294 counts For 8 meter, 25.4 mm (1 inch) = 74 counts
Plus Slack Dist (Cnts)	An extra distance added to the sliding window that might help the process work better. For 1 and 2 meter, 25.4 mm (1 inch) = 294 counts For 8 meter, 25.4 mm (1 inch) = 74 counts
Plus Fault On Cnt	If echo not detected within sliding window within this many cycles, then go to LossEchoState analog output.
Plus Fault Hld Cnt	The number of cycles to hold the analog output at LossEchoState.

PseudoCode:

Each Cycle:

    If Echo is present

        If ThisEchoDist < (SlidingWindowDist + PlusDeltaDist + PlusSlackDist)

            SlidingWindowDist = ThisEchoDist

            SlidingWindowCntr = 0

            Update analog output

        Else

            SlidingWindowDist = SlidingWindowDist + PlusDeltaDist

            SlidingWindowCntr = SlidingWindowCntr + 1

            If (SlidingWindowCntr > PlusFaultOnCnt

                Set analog output to LossEchoState for PlusFaultHldCnt

            Endif

        Endif

    Else

        Do loss-of-echo processing

    Endif



### SM902 -Teaching the Alarm Limit with the Pushbutton

To change either the control or alarm limits, all three limits must be set. Depress the SETUP pushbutton (the multicolor LED rapidly flashes amber to indicate the pushbutton is pressed) until the multicolor LED flashes green (about 3 seconds), and then release the SETUP pushbutton. The multicolor LED continues flashing green indicating the sensor is waiting for the first control limit. Align a flat object parallel to the sensor face at the desired distance position for either control limit, and press the SETUP pushbutton once. Upon release of the SETUP pushbutton, the multicolor LED flashes amber indicating the first control limit is set and the sensor is waiting for the second control limit. Align a flat object parallel to the sensor face at the desired position for the second control limit and press the SETUP pushbutton once. Upon release of the SETUP pushbutton, the multicolor LED flashes amber/green indicating the second control limit is set and the sensor is waiting for the alarm limit. Align a flat object parallel to the sensor face at the desired position for the alarm limit and press the SETUP pushbutton once. Upon release of the SETUP pushbutton, the multicolor LED turns to the color that indicates where the object is located.

### SM903 - Teaching Delays with the Pushbutton

Settable Delays = Period Enable setting the delays by pressing the SETUP pushbutton until the multicolor LED first flashes green and continue pressing until the multicolor LED flashes green and amber (about 7 seconds). After the multicolor LED flashes green and amber, release the SETUP pushbutton and the multicolor continues flashing green and amber indicating the sensor is waiting for the delay-on time. Press the SETUP pushbutton for the desired delay-on time and then release. The multicolor flashes green momentarily indicating a non-minimum delay-on time was accepted, and then multicolor LED flashes green and red indicating the sensor is waiting for the delay-off time. Press the SETUP pushbutton for the desired delay-off time and then release. The multicolor LED flashes green momentarily indicating a non-minimum delay-off time was accepted.

To set the delay-on or delay-off time to the minimum response time, press the SETUP pushbutton twice within one second. After the second release the multicolor LED flashes amber momentarily indicating the minimum delay time was accepted.

Settable Delays = Cycles Enable setting the delays by pressing the SETUP pushbutton until the multicolor LED first flashes green and continue pressing until the multicolor LED flashes green and amber (about 7 seconds). After the multicolor LED flashes green and amber, release the SETUP pushbutton and the multicolor continues flashing green and amber indicating the sensor is waiting for the delay-on time. Press and release the SETUP pushbutton for the desired number of DELAY INTERVAL (CYCLES) millisecond intervals for the delay-on time. After the SETUP pushbutton is not pressed for 5 seconds, the delay-on time is saved, and the multicolor flashes green momentarily indicating the delay-on time was saved. The multicolor LED next flashes green and red indicating the sensor is waiting for the delay-off time. Press and release the SETUP pushbutton for the desired number of DELAY INTERVAL (CYCLES) millisecond intervals for the delay-off time. After the SETUP pushbutton is not pressed for 5 seconds, the delay-off time is saved, and the multicolor flashes green momentarily indicating the delay-on time was saved.

## SM906 – Teaching Analog Response with Pushbutton

The sensor must have Teachable Analog Response enabled in its configuration. Enable teaching analog response by pressing the SETUP pushbutton until multicolor LED first flashes green and continue pressing until multicolor LED flashes green and amber (about 7 seconds). After the multicolor LED flashes green and amber, release the pushbutton. The multicolor LED turns off indicating it is waiting for the analog response input. Each press of the pushbutton doubles the analog response time. One press of pushbutton sets the analog response time to 1 cycle. When the pushbutton is not pressed for 5 seconds, the sensor saves the analog response time and momentarily flashes multicolor LED green acknowledging the input. When the pushbutton is pressed, the multicolor LED turns amber indicating it is accepting the input. The multicolor LED turns red, if the maximum analog response is reached. The maximum analog response is 1024 cycles or 11 presses of pushbutton.

If the teach button is not pressed within 5 seconds after being placed into the Analog Response Teach mode, the sensor flashes the multicolor LED amber the number of times the teach button was pressed in the previous teach.

The following table shows the number of pushbutton presses versus averaging in cycles. Averaging is the number of cycles for the analog signal to reach 95% of its final value.

presses	1	2	3	4	5	6	7	8	9	10	11
cycles	1	2	4	8	16	32	64	128	256	512	1024

## SM900 / SM906 -Dual Power Mode

Dual Power Mode is an operational mode where the sensor alternates between the NormPwr Burst Count and Deadband, and LowPwr Burst Count and Deadband. This allows a closer deadband for high power models, but increases the response time and the accuracy to the object. Consult Schneider Electric SCC before using Dual power modes. If an object is detected within the HOLD LOWPWR distance, then the sensor remains in low power mode. Dual Power is enabled if LowPwr Burst Count is non-zero.

## SM606 / SM900 / SM906 / VM1 Analog -Exponential Averaging

Exponential averaging is used to smooth the echo distance. For the SC606 and VM1 Analog, the program uses TAU directly, which results in the distance average reaching 95 % of actual distance in 3 times the TAU factor. For the SC900 and SC906 the response time is given in cycles, and the program calculates a TAU so that the distance average is 95 % of actual distance in the requested number of cycles.

Each cycle the following calculation is made:

$$\text{DistAvg} = (\text{DistAvg} * (\text{TAU}-1) + \text{DistNow}) \div \text{TAU}$$

This calculation can be expressed by the following equation.

$$\text{DistAvg} = \text{DistNow} * (1 - e^{-n/N})$$

(where N = Response Time in Cycles, and n = Current Cycle count)

Note: when  $n = 3 \cdot N$

$$\text{DistAvg} = \text{DistNow} * (1 - e^{-3}) = \text{DistNow} * (1 - 0.050) = \text{DistNow} * 0.95$$

#### SM900 / SM906 / VM1 - Echo Suppression

Echo Suppression can be used to ignore unwanted objects.

Example 1 (Near Echo Suppression): Measure the contents in bottle, ignoring the echoes from the neck of the bottle.

Example 2 (Near Echo Suppression): Ignore side rails on a conveyor, but detect container in the conveyor.

Example 3 (Near Echo Suppression): Measure stock on a takeup or unwind reel, but ignore horizontal reinforcement bars reel.

Example 4 (Far Echo Suppression): Measure distance to intermittent passing objects, but ignore background surfaces.


Example 5 (Far Echo Suppression): The main object for measuring sometimes becomes tilted and the echo reflects off this object, off a side wall, off the object again, and back to sensor causing a false distance reading. The far echo suppression can be used to ignore this false distance reading.

#### SM900 -Proximity Pulse Length

The SC900 proximity processing can generate a retriggerable pulse whenever the an object enters the sensing window. A possible use for this output is to verify objects are moving pass the sensor as some minimum rate.

## Troubleshooting




The first troubleshooting step is to verify proper operation of the PC serial port with serial cable. To verify the serial port and serial cable, select TEST COM PORT from the DIAGNOSTIC dropdown menu. Follow the directions in the program which tests the serial port and cable by sending a test message to the serial port. Below is a picture of the DB9 pin numbers.





If the serial port passes its test, the next step is to check the DTR line. The DTR line is normal around -10 volts and changes to around +10 volts to power up the sensor. This signal can be checked with a voltmeter.


## Appendix A - AC441 and AC441A Handheld Configurator

The AC441/AC441A can be used to set the window limits of the SC900/SC906 sensors, display distances from the SC900/SC906 sensors, and configure SC900/SC906, SC600/SC606, SC300, and VC1/VC18 sensors. The AC441A is required for the SC300 single output sensors and all the VC1/VC18 series sensors.



For the SC330 and SC3A0 PNP only output sensors, select 300P.  
 For the SC340 and SC3B0 NPN only output sensors, select 300n.





## Installation

The AC441/AC441A is powered with an inline, universal input (85 VAC to 265 VAC, 50/60 Hz) power supply. The power supply is supplied with a country specific AC line/cord and DC output cord.

The AC441/AC441A can also be power with 24 VDC. It requires a 5.5 x 2.1 mm jack with a center negative. The AC441/AC441A with sensor requires a maximum of 220 mA.

The AC441/AC441A can be mounted to a back panel using the included mounting brackets and #8 screws.

## Setup

On power up, the AC441/AC441A displays the distance units (1Inch or Eur) and then the software version for a 1/2 second, and then displays the last selected model type. Press either the AC441/AC441A ▲ or ▼ button to change model.

Model	Display	Special
SC300 with both NPN and PNP outputs	300	
SC300 with NPN only output VC1-N / VC18-N	300n	requires AC441A
SC300 with PNP only output VC1-P / VC18-P VC1-C / VC18-C VC1-V / VC18-V	300P	requires AC441A
SC600	600	
SC606	606	
SC900	900	
SC906	906	

Figure 1 - Available Models

If 900 or 906 is displayed, then press and release the **MODE** button to change modes. Each press and release of the **MODE** button advances to the next MODE (Figure 2). If 300, 600, or 606 is displayed, then only one mode is available (Figure 3).

Mode	7-Segment Display	Near LED	Far LED
900/906			
Display Distance/Configure	[model] / 9.999, 99.99 or 999.9	on	on
Change Near Limit/Configure	[model] / 9.999, 99.99 or 999.9	on	off
Change Far Limit/Configure	[model] / 9.999, 99.99 or 999.9	off	on

Figure 2 - AC441/AC441A SC900/SC906 Modes

Mode	7-Segment Display	Near LED	Far LED
Configure SC300	300/300P/300n	off	off
Configure SC600/SC606	600/606	off	off
Configure VC1 / VC18	300P/300n	off	off

Figure 3 - AC441/AC441A SC300/VC1/SC600/SC606 Configure Mode



**Changing Distance Units:** The AC441/AC441A can display the sensor distances and limits in either inches or meters. When the AC441/AC441A is powered on, the AC441/AC441A displays the current distance units (1Inch for English, Eur for Metric). If the distance units do not display, call Schneider Electric for assistance. To change the distance units, while pressing the **MODE** button apply power to the AC441/AC441A. The AC441/AC441A displays the current distance units. Press and release the ▲ or ▼ button to change the distance units, and then release the **MODE** button. The distance units are saved in non-volatile memory.

English(inches) 1 & 2 meter models, the distances are displayed and limits entered in inches with 2 decimal places ( 99.99). 8 meter models, the distances are displayed and limits entered in inches with 1 decimal place (999.9).

Metric (meters) Distances are displayed and limits are entered in meters with 3 decimal places (9.999).



**Configuring Sensors** See the "Programming SC300 Series Sensors" on page 6, "Programming SC600 or SC606 Series Sensors" on page 8, "Programming SC900 or SC906 Series Sensors" on page 10, or "Programming VC1 / VC18 Discrete or Analog Sensors" on page 11.

**Display Distance Mode (900 and 906 only):** When selected, the display shows the selected model number and both the far and near LEDs are on. Press the **ENTER** button to power up the sensor and request distances from the sensor. While powering up the sensor, the decimal points are illuminated as an indication power is applied to the sensor. When the sensor is powered up, the AC441/AC441A continuously displays the current distance. Press the **ENTER** button to power off the sensor.


**Change Near Limit (900 and 906 only):** When selected, the display shows the selected model number, the near LED is on and the far LED is off. Press the **ENTER** button to request the current limits from the sensor. After the limits are received from the sensor, the display shows the near limit. Press the ▲ or ▼ button to change the near limit in the AC441/AC441A only. To change the near limit in the sensor, you must press the **ENTER** button. When the **ENTER** button is pressed, the AC441/AC441A sends the limits to the sensor, and then displays 'donE' when the near limit has been successfully saved by the sensor. If unsuccessful, the display shows 'Err'. Press the **ENTER** button to erase either the 'Err' or 'donE' display.

**Change Far Limit (900 and 906 only):** When selected the display shows the selected model number, the near LED is off and the far LED is on. Press the **ENTER** button to request the current limits from the sensor. After the limits are received from the sensor, the display shows the far limit. Press the ▲ or ▼ button to change the far limit in the AC441/AC441A only. To change the far limit in the sensor, you must press the **ENTER** button. When the **ENTER** button is pressed, the AC441/AC441A sends the limits to the sensor, and then displays 'donE' when the near limit has been successfully saved by the sensor. If unsuccessful, the display shows 'Err'. Press the **ENTER** button to erase either the 'Err' or 'donE' display.


### PC Get Distances from SC900/SM900 or SC906/SM906

When the AC441/AC441A is displaying distances, the distance is also being sent to the RS232 serial port. To remotely power up the sensor with the AC441/AC441A, set the DTR signal high. When powered up, the AC441/AC441A uses the last selected model. To select the desired model, press the  or  button until the desired model is displayed. Then, press the **ENTER** button which saves the model number in non-volatile memory.

## Wiring and Dimensions



## General Specifications

<b>Power Supply:</b>	Inline, universal input: 85 VAC to 265 VAC, 50/60 Hz Output: 24 VDC, 630 mA Supplied with country specific AC line cord/plug and DC output cord. Both cords are 1.8 m (6 feet) in length  The AC441/AC441A requires 220 mA at 24 volts connected to a 5.5 x 2.1 mm jack with center negative
<b>Other Connections:</b>	6-pin quick disconnect for sensor DB9 female connector for PC interface
<b>Sensor Mounting Distance:</b>	45.7 m (150 ft.) maximum
<b>Display:</b>	4-digit 7-segment 10 mm (0.4 in.) tall red LED with decimal point
<b>Dimensions:</b>	165.5 mm (6.52 in.) by 70.5 mm (2.78 in.) by 29.0 mm (1.14 in.)
<b>Operating Temperature</b>	0°C to 50°C (32°F to 122°F ) @ 10-90% non-condensing humidity. Not suitable for permanent outdoor use.
<b>Ratings and Certifications:</b>	 CE Mark Compliant